052IJ–05

DTC	B2795	UNMATCHED KEY CODE

CIRCUIT DESCRIPTION

This DTC is output when a key with a key code that has not been registered in the ECU is inserted into the ignition key cylinder.

DTC No.	DTC Detection Condition	Trouble Area
B2795	Key with unregistered key code is inserted	• Key

INSPECTION PROCEDURE

1	DELETE DTC AND INSERT ALL PRESENTLY AVAILABLE KEYS TO CHECK WHETHER ENGINE STARTS OR NOT

OK ⟩ **NO PROBLEM (BECAUSE OF KEY RE–REGISTRATION)**

NG

REPLACE KEY THAT WILL NOT START ENGINE