

: Parts Location

C	ode	See Page	Code	See Page	Code	See Page
B6	Α	42 F10		38 (*1)	L1	45
C	C11 42		110	40 (*2)	L2	45
F9		38 (*1)	J4	43	R6	45
'	9	40 (*2)	J11	44	R7	45

: Relay Blocks

	Code	See Page	Relay Blocks (Relay Block Location)
I	1	22	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)	
2E	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)	
2G		Englis Noon wall wile and briver olde 0/b (Lower Filliam aller)	
2K	28	Floor Wire and Driver Side J/B (Lower Finish Panel)	

: Ground Points

Code	See Page	Ground Points Location	
EB	48 (*1)	Right Fender	
	49 (*2)	rightrender	
EC	48 (*1)	Left Fender	
	49 (*2)	Lettrender	
IK	50	Instrument Panel Brace LH	
BQ	52	Front Side of Rear Quarter Wheel House LH	
BS	52	Lower Back Panel Center	