L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
A 1	A/C Ambient Temp. Sensor	90980-11070	В8	Body ECU	90980-10803
A 2	A/C Condenser Fan Motor	90980-10928	В9	Buckle SW LH	90980–11950
A 3	A/C Lock Sensor	90980–11016	B10	Buckle SW (Front Passenger's Side) (TMC Made)	90980–11019
	A/C Magnetic Clutch			Buckle SW (Front Passenger's Side)	90980–10947
	A/T Indicator Light SW	90980–12362		(TMMK Made)	
A 4	Back-Up Light SW		B11	Buckle SW LH (TMC Made)	90980–10942
1.0	Park/Neutral Position SW			Buckle SW LH (TMMK Made)	90980–11034
A 6	ABS Speed Sensor Front LH	90980–11002		Seat Position Airbag Sensor (TMC Made)	90980–10942
A 7	ABS Speed Sensor Front RH			Seat Position Airbag Sensor (TMMK Made)	90980–11034
A 8	Air Fuel Ratio Sensor (Bank 1 Sensor 1)		C 1	Camshaft Position Sensor	90980–10947
A 9	Air Fuel Ratio Sensor (Bank 1 Sensor 1)	90980–11178	C 2	Counter Gear Speed Sensor	90980–11156
A10	Air Fuel Ratio Sensor (Bank 2 Sensor 1)		C 3	Crankshaft Position Sensor	90980-10947
A11	Airbag Sensor Front LH	90980–11856		Cigarette Lighter	†
A12	Airbag Sensor Front RH		C 4	Cigarette Lighter Illumination	90980–11606
A13	A/C Control Assembly	90980–12169		Clock (Automatic A/C)	90980-12200
A14	A/C Room Temp. Sensor		C 5	Clock (Manual A/C)	90980–11911
A15	A/C Solar Sensor	90980–11918	C 6	Clutch Start SW	90980–10825
A16	A/C Thermistor		C 7	Combination Meter	90980–12170
A18	Accelerator Position Sensor	90980–11144	C 8	Combination Meter	90980–12200
A19	Air Inlet Control Servo Motor	90980–11909	C 9	Combination SW	90980–11594
A20	Air Mix Control Servo Motor		C10	Combination SW	90980–12183
A21	Air Vent Mode Servo Motor (Automatic A/C)	90980–11909	C11	Combination SW	90980–11672
	Air Vent Mode Servo Motor (Manual A/C)	90980–11989	C12	Cruise Control Clutch SW	90980–10906
A22	Airbag Sensor Assembly	90980–12392	C13	Choke Coil	90980–11259
A23	Airbag Sensor Assembly	90980–12391	C14	Curtain Shield Airbag Sensor LH	90980–12241
A24	Airbag Sensor Assembly	90980–12390	C15	Curtain Shield Airbag Sensor RH	
A27	Airbag Squib (Steering Wheel Pad)	90980–12160		Curtain Shield Airbag Squib LH (TMC	00080 12210
A28	Automatic Light Control Sensor	90980–11107	C16	Made) Curtain Shield Airbag Squib LH (TMMK Made) Curtain Shield Airbag Squib RH (TMC	90980–12219 90980–11884
A32	ABS Speed Sensor Rear LH	90980–11060			
A33	ABS Speed Sensor Rear RH	11000			
A34	Adjustable Pedal Motor	90980-10825		Made)	90980–12219
A35	Adjustable Pedal SW	90980–11090	C17	Curtain Shield Airbag Squib RH (TMMK Made)	90980–11884
A36	A/T Shift Lever Illumination	90980–12221			
7,50	Transmission Control SW		D 1	Diode (A/C No.1)	90980–11071
A37	Airbag Squib (Front Airbag Sensor Assembly)	90980–12160	D 2	Diode (A/C No.2)	90980–10962
A38	A/C Amplifier	90980–10807	D 3	Data Link Connector 3	90980–11665
A39	A/C Control Assembly	90980-10807	D 4	Diode (Luggage Compartment Light)	90980–10962
A40	A/C Control Assembly	90980-12259	D 5	Door Control Receiver	90980–11909
	Back-Up Light SW		D 6	Door Courtesy SW Front LH	90980–10871
B1		90980-11250	D 7	Door Courtesy SW Front RH	
B 2	Brake Fluid Level Warning SW	90980-11207	D 8	Door Courtesy SW Rear LH	
B 3	Blower Motor Blower Motor Controller	90980-10903	D 9	Door Courtesy SW Rear RH	
B 4		90980–11676 90980–11136		Door Key Lock and Unlock SW Front LH	90980–12226
B 5	Blower Resistor		D10	Door Lock Motor Front LH	
B 6	Body ECU	90980–11915		Door Unlock Detection SW Front LH	
В7	Body ECU	90980–11913			

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
	Door Key Lock and Unlock SW Front RH		H 4	Headlight RH (Low)	90980–11096
D11	Door Lock Motor Front RH	90980–12226	H 6	Heated Oxygen Sensor (Bank 1 Sensor 2) (1MZ–FE, 3MZ–FE)	00000 10000
	Door Unlock Detection SW Front RH				90980–10869
D12	Door Lock Control SW Front LH	90980–12122		Heated Oxygen Sensor (Bank 1 Sensor 2) (2AZ–FE)	90980–11028
	Power Window Master SW			Heated Oxygen Sensor (Bank 2 Sensor 2)	
	Door Lock Control SW RH (TMC Made)	82824–12270	H 7	, , , , , , , , , , , , , , , , , , , ,	90980–11028
D13	Door Lock Control SW RH (TMMK Made)	90980–10797		Horn (High)	90980–10619
	Door Lock Motor Rear LH		H 9	Horn (Low) Heater Control SW	90980–12153
D14	Door Unlock Detection SW Rear LH	90980–12226	H11	Heater Control SW	90980-12153
	Door Lock Motor Rear RH		ПП		
D15	Door Unlock Detection SW Rear RH		H12	High Mounted Stop Light (w/ Rear Spoiler)	90980-11060
D16	Daytime Running Light Resistor	90980–10928	1140	High Mounted Stop Light (w/o Rear Spoiler)	90980-11148
E 3	Electronically Controlled Transmission	00000 42226	H13	Heated Oxygen Sensor (Bank 1 Sensor 3) Ignition Coil and Igniter No.1	90980–11028
E 3	Solenoid	90980–12326	11	Ignition Coil and Igniter No.1	
	Engine Coolant Temp. Sensor (1MZ–FE, 3MZ–FE)	90980–10737		Ignition Coil and Igniter No.2	
E 4	Engine Coolant Temp. Sensor (2AZ–FE)	90980–10735	13	Ignition Coil and Igniter No.4	90980–11885
E 5	Engine Coolant Temp. Sensor (2A2–FE) Engine Hood Courtesy SW	90980-10735		<u> </u>	
	,		15	Ignition Coil and Igniter No.5 Ignition Coil and Igniter No.6	
E 6	Engine Control Module	90980-12525	16	•	00000 44450
E 7	Engine Control Module	90980-12146	17	Injector No.1 (1MZ–FE, 3MZ–FE)	90980–11153
E 8	Engine Control Module	90980–12143		Injector No.1 (2AZ–FE)	90980–11875
E 9	Engine Control Module	90980–12145	18	Injector No.2 (1MZ–FE, 3MZ–FE)	90980–11153
E10	Engine Control Module	90980–12144		Injector No.2 (2AZ–FE)	90980–11875
F1	Front Fog Light LH	90980–11096	19	Injector No.3 (1MZ–FE, 3MZ–FE)	90980–11153
F 2	Front Fog Light RH			Injector No.3 (2AZ–FE)	90980–11875
F 5	Front Wiper Motor	90980–11599	110	Injector No.4 (1MZ–FE, 3MZ–FE)	90980–11153
F6	Front Door Speaker LH (TMC Made)	82824–12260	144	Injector No.4 (2AZ–FE)	90980–11875
	Front Door Speaker LH (TMMK Made)	90980–10935	111	Injector No.5	90980–11153
F 7	Front Door Speaker RH (TMC Made)	82824–12260	l12	Injector No.6	
	Front Door Speaker RH (TMMK Made)	90980–10935	I13	Ignition Key Cylinder Light	90980–10679
F8	Fuel Pump	90980–11077	114	Ignition Key Cylinder Light	90980–12092
	Fuel Sender			Transponder Key Amplifier	
F 9	Front Parking Light LH	90980–10887	I15	Ignition SW	90980–11615
F10	Front Parking Light RH		I16	Inner Mirror	90980–11794
F11	Front Turn Signal Light LH (TMC Made)	90980–11019	l17	Interior Light	90980–10908
	Front Turn Signal Light LH (TMMK Made)	90980–11020	I18	Intake Air Control Valve	90980–11599
F12	Front Turn Signal Light RH (TMC Made)	90980–11019	J 1	Junction Connector	90980–12346
	Front Turn Signal Light RH (TMMK Made)	90980–11020	J 2	Junction Connector	90980–11542
G 1	Generator	90980-09213	J 4	Junction Connector	90980–10976
G 2	Generator	90980–11964	J 5	Junction Connector	90980–11661
G 3	Glove Box Light and SW	90980–11098	J 6	Junction Connector	
G 4	Garage Door Opener		J 7	Junction Connector	
	Moon Roof Control SW	90980–10789	J 8	Junction Connector	
	Personal Light		J11	Junction Connector	90980–10976
H 1	Headlight LH (High)	90980–11095	J13	Junction Connector	
H 2	Headlight LH (Low)	90980–11096	J14	Junction Connector	90980–12355
H 3	Headlight RH (High)	90980–11095	J15	Junction Connector	

L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
J16	Junction Connector	00000 40055	01	Oil Pressure SW	90980–11363
J17	Junction Connector	90980–12355	03	Occupant Classification ECU	90980-12357
J18	Junction Connector		04	Occupant Classification ECU	90980–12356
J19	Junction Connector	90980–12374	O 5	Occupant Classification Sensor Front RH	90980-12354
J20	Junction Connector		06	Occupant Classification Sensor Rear RH	00000 40050
J21	Junction Connector		07	Occupant Classification Sensor Front LH	90980–12353
J22	Junction Connector	90980–11915	0.8	Occupant Classification Sensor Rear LH	90980–12354
J23	Junction Connector	90960-11915	09	Occupant Classification ECU	90980–12357
K 1	Keyless Buzzer	90980-11142	O10	Occupant Classification ECU	90980–12356
K 2	Knock Sensor (Bank 1)	90980–11875		Occupant Classification Sensor Front RH	90980–12353
К3	Knock Sensor (Bank 1) (1MZ-FE)	90980–11166	O11	(TMC Made)	
K 3	Knock Sensor (Bank 1) (3MZ-FE)	90980–11875		Occupant Classification Sensor Front RH (TMMK Made)	90980–12354
K 4	Knock Sensor (Bank 2) (1MZ-FE)	90980-11166	012	Occupant Classification Sensor Rear RH	
11.4	Knock Sensor (Bank 2) (3MZ-FE)	90980–11875	O13	Occupant Classification Sensor Front LH	90980–12353
L 1	License Plate Light LH	90980–11148		Occupant Classification Sensor Rear LH	90980–12353
L 2	License Plate Light RH	30300 11140	014	(TMC Made)	
L 3	Luggage Compartment Door Key Unlock SW	90980–11060		Occupant Classification Sensor Rear LH (TMMK Made)	90980–12354
L4	Luggage Compartment Door Opener Motor	90980–10825	P 1	Power Steering Oil Pressure SW	90980–11428
L 4	Luggage Compartment Light SW	90960-10625	P 2	Pressure SW	90980–10943
L 5	Luggage Compartment Light	90980–11148		Parking Brake SW (w/ Power Adjustable	90980–10860
M 1	Mass Air Flow Meter	90980–11317	P3	Pedals)	
	Mirror Heater LH (TMC Made w/ Mirror Heater)	90980–10558		Parking Brake SW (w/o Power Adjustable Pedals)	90980–10871
	Mirror Heater LH (TMC Made w/o Mirror	90980–10395	P 6	Power Outlet (Front)	90980–10760
	Heater)			Power Outlet (Rear)	90980–10860
M 2	Mirror Heater LH (TMMK Made)	90980–11488		Power Window Control SW Front RH (TMC Made)	82824–12230
	Remote Control Mirror LH (TMC Made w/ Mirror Heater)	90980–10558		Power Window Control SW Front RH (TMMK Made)	90980–10789
	Remote Control Mirror LH (TMC Made w/o Mirror Heater)	90980-10395		Power Window Control SW Rear LH	90980–10789
	Remote Control Mirror LH (TMMK Made)	90980–11488		Power Window Control SW Rear RH (TMC	
	Mirror Heater RH (TMC Made w/ Mirror			Made)	82824–12230
	Heater) Mirror Heater RH (TMC Made w/o Mirror	90980–10558	P 8	Power Window Control SW Rear RH (TMMK Made)	90980–10789
	Heater)	90980–10395		Power Window Motor Front LH (TMC Made)	82824–12270
Mo	Mirror Heater RH (TMMK Made)	90980–11488		Power Window Motor Front LH (TMMK	90980–10797
М3	Remote Control Mirror RH (TMC Made w/ Mirror Heater)	90980–10558		Made) Power Window Motor Front RH (TMC	82824–12270
	Remote Control Mirror RH (TMC Made w/o Mirror Heater)	90980–10395		Made) Power Window Motor Front RH (TMMK	90980–10797
	Remote Control Mirror RH (TMMK Made)	90980–11488	<u> </u>	Made)	30300-10737
M 4	Moon Roof Control ECU and Motor (TMC Made)	90980–10997	P11 P12	Power Window Motor Rear LH Power Window Motor Rear RH	90980–10797
	Moon Roof Control ECU and Motor (TMMK 00080 1	90980–10799	P13	Pretensioner LH	90980–12253
	Made)		P14	Pretensioner RH	
N 1	Noise Filter (Ignition)	90980–10843			
N 4	Noise Filter (Stop and Dome)	90980-10860			

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
P15	Power Seat Control SW (Driver's Seat)	90980–10997	S11	Steering Sensor	82824-45030
P16	Power Seat Control SW (Front Passenger's		S12	Stereo Component Amplifier	90980-10848
1 10	Seat)		S13	Stereo Component Amplifier	90980-10807
P17	Power Seat Motor (Driver's Seat Front Vertical Control)	90980–10825	S14	Stop Light SW	90980–11118
P18	Power Seat Motor (Driver's Seat Lifter		S15	Side Airbag Sensor LH	90980–12241
0	Control)		S16	Side Airbag Sensor RH	
P19	Power Seat Motor (Driver's Seat Reclining Control)		S17	Seat Heater LH	90980–10906 90980–11864 90980–10619
	Power Seat Motor (Driver's Seat Slide		S18	Seat Heater RH	
P20	Control)		S19 S20	Side Airbag Squib BH	
P22	Power Seat Motor (Front Passenger's Seat Front Vertical Control)		T 1	Side Airbag Squib RH Theft Deterrent Horn	
	Power Seat Motor (Front Passenger's Seat		T 4	Turbine Speed Sensor	90980-10019
P23	Lifter Control)		T 5	Theft Deterrent ECU	90980-11138
P24	Power Seat Motor (Front Passenger's Seat		T 6	TRAC OFF SW	90980-11423
Г24	Reclining Control)		T 7	Turn Signal Flasher Relay	90980-11013
P25	Power Seat Motor (Front Passenger's Seat Slide Control)		T 9	Tweeter LH	90980-10799
	Power Seat Control SW (Driver's Seat		T10	Tweeter RH	90980–11013
P28	Lumbar Support Control)	90980–10789	110	Transponder Key Computer (TMC Made)	90980–12423
P29	Power Seat Motor (Driver's Seat Lumbar	90980–10825	T11	Transponder Key Computer (TMK Made)	90980-12423
F 29	Support Control)	90900-10025		Throttle Control Motor	90960-11911
R 1	Radiator Fan Motor	90980–10928	T12	Throttle Position Sensor	90980–11858
R 2	Radio and Player	90980–10997	U 1		00000 10000
R 3	Radio and Player	90980–10996	V 3	Unlock Warning SW VSV (AICV)	90980–10860 90980–11156
	Radio and Player (w/o Navigation System)	90980–12038	V 3	VSV (Canister Closed Valve)	90980-11156
R 4	Radio and Player with Display (w/ Navigation System)		V 4	VSV (EVAP)	90980-11659
R 5	Rheostat	90980–11950	V 7	VVT Solenoid	90980–11162
R 6	Rear Combination Light LH		V 8	VSC Warning Buzzer	90980–10906
R 7	Rear Combination Light RH	90980–11587	V 9	Vanity Light LH	
R 8	Rear Speaker LH		V10	Vanity Light RH	90980–10621
R 9	Rear Speaker RH	90980–11299		Vapor Pressure Sensor (TMC Made)	90980–11143
R10	Remote Control Mirror SW	90980–11657	V11	Vapor Pressure Sensor (TMMK Made)	90980–11860
R12	Radio and Player with Display	90980–11909	V13	VSV (ACIS No.1)	
	Radio and Player (w/o Navigation System)	90980–12259	V14	VSV (ACIS No.2)	90980–11149
R13	Radio and Player with Display (w/		V15	VSV (ACM)	90980–11156
	Navigation System)		V16	VVT Sensor LH	90980–10947
	Skid Control ECU with Actuator (TMC Made w/o VSC)	90980–12020	V17	VVT Sensor RH	
S 1	Skid Control ECU with Actuator (TMMK Made w/o VSC)	90080–98317	V18	VVT Solenoid LH	90980–11162
0 1			V19	VVT Solenoid RH	
	Skid Control ECU with Actuator (w/ VSC)	90980–12297	W 1	Washer Level Sensor	90980–11068
S 2	Starter	90980–11400	W 2	Washer Motor	90980-10981
S 3	Starter	90980-09463	W 3	Water Temp. SW No.1	90980–11235
S 4	Seat Heater SW (Driver's Seat)	90980–10964	W 4	Water Temp. SW No.2	90980–11243
S 5	Seat Heater SW (Front Passenger's Seat)	90980–10933	Y 1	Yaw Rate Sensor	90980–11904
S 6	Shift Lock Control ECU	90980–11909	Z 1	Option Connector (TVIP ECU)	90980–10860