
DTC C1251/51 PUMP MOTOR IS LOCKED/OPEN CIRCUIT IN PUMP MOTOR GROUND

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1251/51	 Actuator pump motor does not operate properly. Open in actuator pump motor circuit continues for at least 2 sec. 	Brake actuator assy

WIRING DIAGRAM



INSPECTION PROCEDURE

NOTICE:

When replacing the brake actuator assy, perform zero point calibration (see page 05-987).

1 | PERFORM ACTIVE TEST BY HAND-HELD TESTER(MOTOR RELAY)

- (a) Connect the hand-held tester to the DLC3.
- (b) Start the engine.
- (c) Select ACTIVE TEST mode on the hand-held tester.
- (d) Check for operation sound of the ABS motor individually when operating it with the hand-held tester.

Item	Vehicle Condition / Test Details	Vehicle Condition / Test Details
ABS MOT RELAY	ABS motor relay / ON/OFF	ON: Motor relay ON

OK:


The operation sound of the ABS motor should be heard.



OK

REPLACE BRAKE ACTUATOR ASSY (SEE PAGE 32-63)

2 INSPECT HARNESS AND CONNECTOR(GND2 OF SKID CONTROL ECU AND BODY GROUND)



- (a) Disconnect the skid control ECU connector S1.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:


Tester Connection	Specified Condition	
S1-1 (GND2) - Body ground	Below 1 Ω	
NG REPAIR OR R	EPLACE HARNESS OR	

3 RECONFIRM DTC

- (a) Clear the DTCs (see page 05-1002).
- (b) Turn the ignition switch to the ON position.
- (c) Are the same DTCs recorded? (see page 05–1002)

HINT:

It is suspected that the DTCs output was caused by poor connection of the connector terminal.



YES

REPLACE BRAKE ACTUATOR ASSY (SEE PAGE 32-63)