





B-W B-W




Engine Control for 1MZ-FE and 3MZ-FE








- * 2 : TMC Made
- * 3 : TMMK Made
- * 5 : Automatic A/C * 7 : Manual A/C





System Outline

This system utilizes an engine control module and maintains overall control of the engine, transmission and so on. An outline of the engine control is explained here.

1. Input Signals

(1) Engine coolant temp. signal circuit

The engine coolant temp. sensor detects the engine coolant temp. and has a built–in thermistor with a resistance which varies according to the water temp. is input into TERMINAL THW of the engine control module as a control signal.

(2) Intake air temp. signal circuit

The intake air temp. sensor is installed in the mass air flow meter and detects the intake air temp., which is input as a control signal into TERMINAL THA of the engine control module.

(3) Oxygen sensor signal circuit

The oxygen density in the exhaust gases is detected and input as a control signal into TERMINALS OX1B and OX2B of the engine control module. To maintain stable detection performance by the heated oxygen sensor, a heater is used for warming the sensor. The heater is also controlled by the engine control module (HT1B and HT2B).

(4) Throttle signal circuit

The throttle position sensor detects the throttle valve opening angle as a control signal, which is input into TERMINALS VTA1 and VTA2 of the engine control module.

(5) Vehicle speed signal circuit

The vehicle speed sensor, detects the vehicle speed and input to ABS speed sensor of the skid control ECU with actuator, from skid control ECU with actuator to TERMINAL SPD of the engine control module, Via combination meter.

(6) Park/Neutral position SW signal circuit

The Park/Neutral position SW detects whether the shift position is in neutral, parking or not, and inputs a control signal into TERMINAL NSW of the engine control module.

(7) A/C SW signal circuit

The A/C control assembly (Automatic A/C) or heater control SW (Manual A/C) inputs the A/C operations into TERMINAL A/CS of the engine control module as a control signal.

(8) Battery signal circuit

Voltage is always supplies to TERMINAL BATT of the engine control module.

If you turn on the ignition SW, the current goes from TERMINAL MREL of the engine control module to the EFI relay and put on the relay, and the voltage related to the engine control module operation is supplied to TERMINALS +B and +B2 of the engine control module through the EFI relay.

(9) Intake air volume signal circuit

Intake air volume is detected by the mass air flow meter and a signal is input into TERMINAL VG of the engine control module as a control signal.

(10) Starter signal circuit

To confirm whether the engine is cranking, the voltage applied to the starter motor during cranking is detected and the signal is input into TERMINAL STA of the engine control module as a control signal.

(11) Engine knock signal circuit

Engine knocking is detected by the knock sensor No.1 and No.2, then the signals are input into TERMINALS KNK1 and KNK2 of the engine control module as a control signal.

(12) Air fuel ratio signal circuit

The air fuel ratio is detected and input as a control signal into TERMINALS A1A+, A2A+ of the engine control module.

Engine Control for 1MZ-FE and 3MZ-FE

2. Control System

* SFI system

The SFI system monitors the engine condition through the signals, which are input from each sensor to engine control module. The best fuel injection volume is decided based on this data and the program memorized by the engine control module, and the control signal is output to TERMINALS #10, #20, #30, #40, #50 and #60 of the engine control module to operate the injector (Inject the fuel). The SFI system produces control of fuel injection operation by the engine control module in response to the driving conditions.

* ESA system

The ESA system monitors the engine condition through the signals, which are input to the engine control module from each sensor. The best ignition timing is decided according to this data and the memorized data in the engine control module, and the control signal is output to TERMINALS IGT1, IGT2, IGT3, IGT4, IGT5 and IGT6. This signal controls the igniter to provide the best ignition timing for the driving conditions.

* Heated oxygen sensor heater control system

The heated oxygen sensor heater control system turns the heater on when the intake air volume is low (Temp. of exhaust emissions is low), and warms up the heated oxygen sensor to improve detection performance of the sensor. The engine control module evaluates the signals from each sensor, current is output to TERMINALS HT1B and HT2B, controlling the heater.

* Air fuel ratio sensor heater control system

The air fuel ratio sensor heater control system turns the heater on when the intake air volume is low (Temp. of exhaust emission is low), and warms up the air fuel ratio sensor to improve detection performance of the sensor.

The engine control module evaluates the signals from each sensor, current is output to TERMINALS HA1A and HA2A, controlling the heater.

* ACIS

ACIS includes a valve in the bulkhead separating the surge tank into two parts. This valve is opened and closed in accordance with the driving conditions to control the intake manifold length in two stages for increased engine output in all ranges from low to high speeds.

The engine control module judges the engine speed by the signals from each sensor and outputs current to the TERMINAL ACIS to control the VSV (ACIS No.1).

3. Diagnosis System

With the diagnosis system, when there is a malfunction in the engine control module signal system, the malfunctioning system is recorded in the memory.

4. Fail-Safe System

When a malfunction occurs in any systems, if there is a possibility of engine trouble being caused by continued control based on the signals from that system, the fail—safe system either controls the system by using data (Standard values) recorded in the engine control module memory or else stops the engine.

: Parts Location

Code		See Page	Code		See Page	Code		See Page
A4		38 (*1)	13		39 (*1)	S1	Α	39 (*1)
A9		38 (*1)	14		39 (*1)		В	39 (*1)
A10		38 (*1)	15		39 (*1)		С	39 (*1)
A13	Α	42	16		39 (*1)	S14		43
A18		42	17	Α	39 (*1)	T11	Α	43
A23	В	42	18	Α	39 (*1)	' ' '	В	43
C3	Α	38 (*1)	19	Α	39 (*1)	T′	12	39 (*1)
C7	Α	42	I10	Α	39 (*1)	V3		39 (*1)
C8	В	42	I1	1	39 (*1)	V4	А	45
D	3	42	l12		39 (*1)	V4	В	45
E4	Α	38 (*1)	I1	5	43	V6	Α	39 (*1)
E6	Α	42	J	1	43	V11	Α	45
E7	В	42	J:	2	43	VII В		45
E8	С	42	J11		44	V13		39 (*1)
E9	D	42	J22	Α	43	V14		39 (*1)
E10	Е	42	J23	В	43	V15		39 (*1)
F8		44	К3	Α	39 (*1)	V.	16	39 (*1)
H6	Α	38 (*1)	NO	В	39 (*1)	V.	17	39 (*1)
H7		38 (*1)	K4	Α	39 (*1)	V.	18	39 (*1)
H10	В	43	N4	В	39 (*1)	V.	19	39 (*1)
I.	1	39 (*1)	M1		39 (*1)			
12		39 (*1)	P1		39 (*1)			

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)	
1A			
1B			
1C			
1D	25	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)	
1E			
1H			
1J			
1K	25	Engine Wire and Engine Room J/B (Engine Compartment Left)	
1L	20	Engine vine and Engine Reemen (2) (Engine comparation (2017)	
2A	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)	
2E	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)	
2G	20		
2K	28	Floor Wire and Driver Side J/B (Lower Finish Panel)	
2L		Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)	
2M	29		
20			
2P			
2R			
3A	34	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)	
3B	J-4	instrument and the and the assenger stack of b (morament)	

Engine Control for 1MZ-FE and 3MZ-FE

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
EB1	48 (1MZ-FE)	Engine Wire and Sensor Wire (Left Bank of Cylinder Head)	
EB2	48 (3MZ-FE)		
IC2	50	Instrument Panel Wire and Floor Wire (Left Kick Panel)	
ID1	50	Engine Room Main Wire and Floor Wire (Left Side of Driver Side J/B)	
IF1			
IF2		Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)	
IF3	50		
IF4			
IF6			
IJ1	51	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH)	
IL1	- 51	Engine Wire and Instrument Panel Wire (Behind the Glove Box)	
IL2			
IO1	51	Engine Room Main Wire and Engine Room Main Wire (Right Side of the Instrument Panel)	

: Ground Points

Code	See Page	Ground Points Location	
EC	EC 48 (*1)	Left Fender	
ED 40 (1)	40(1)		
EE	48 (*1)	Left Side of Cylinder Head	
EF	48 (*1)	Right Side of Cylinder Head	
II	50	Cowl Side Panel LH	
BQ	52	Front Side of Rear Quarter Wheel House LH	