WIRELESS[DOOR[LOCK[CONTROL[SYSTEM HOW]TO[PROCEED[WITH[TROUBLESHOOTING

0564T_0

HINT:
Troubleshoot[]n[accordance[with[]]he[]procedure[]on[]]he[]ollowing[]pages.
1 VEHICLE[BROUGHT[IN
2 CUSTOMER[PROBLEM[ANALYSIS[CHECK[AND[\$YMPTOM[CHECK[See[page 05-1241)]]]
3 DIAGNOSTIC TROUBLE CODE CHECK (See page 05-1242)
(a) Check the diagnostic trouble code. (1) Without code outputs, proceed to "A". (2) With code outputs, proceed to "B". B Go to step 6
A
4 PROBLEM SYMPTOMS TABLE (See page 05-1246)
(a) Without applicable symptoms, proceed to "A".(b) With applicable symptoms, proceed to "B".
B Go to step 6
A
5 PERFORM TROUBLESHOOTING IN FOLLOWING METHOD, DEPENDING ON MALFUNCTION SYMPTOM
(a) Terminals of ECU. See page 05-1244) (b) On-vehicle inspection. See page 73-8)
6 ADJUSTMENT, REPAIR OR REPLACEMENT
END