

FRONT SIDE MEMBER (ASSY): TMMK Made REPLACEMENT

- 1. REMOVE RADIATOR UPPER SUPPORT (See page BP-1)
- 2. REMOVE RADIATOR SUPPORT UPPER BRACE (See page BP-3)
- 3. REMOVE RADIATOR SIDE SUPPORT (See page BP-5)
- 4. REMOVE FRONT CROSSMEMBER (See page BP-8)
- 5. REMOVE COWL TOP SIDE REINFORCEMENT (See page BP-39)
- 6. REMOVE FRONT BODY PILLAR LOWER GUSSET (See page BP-41)
- 7. REMOVE FRONT FENDER APRON (See page BP-19)
- 8. REMOVE FRONT SIDE MEMBER
- (a) Leave the floor side member No.4 reinforcement to the vehicle, remove the front side member.







9. INSTALL FRONT SIDE MEMBER

- (a) Remove the floor side member No.4 reinforcement from the new parts of front side member.
- (b) Temporarily install the new parts and measure each part in accordance with the body dimension diagram.

HINT:

Make sure each measurement is correct, as this parts affects the front wheel alignment.





- 10. MEASURING THE ENGINE COMPARTMENT DIMENSIONS (See page BP-100)
- 11. MEASURING THE UNDER BODY DIMENSIONS (See page BP-100)
- 12. INSTALL FRONT FENDER APRON (See page BP-19)
- 13. INSTALL FRONT BODY PILLAR LOWER GUSSET (See page BP-41)
- 14. INSTALL COWL TOP SIDE REINFORCEMENT (See page BP-39)
- 15. INSTALL FRONT CROSSMEMBER (See page BP-8)
- 16. INSTALL RADIATOR SIDE SUPPORT (See page BP-5)
- 17. INSTALL RADIATOR SUPPORT UPPER BRACE (See page BP-3)
- 18. INSTALL RADIATOR UPPER SUPPORT (See page BP-1)
- 19. APPLYING SEALER TO THE ENGINE COMPARTMENT (See page PC-1)
- 20. APPLYING SEALER TO THE INSIDE OF THE VEHICLE (See page PC-2)
- 21. APPLYING UNDER COATING (See page PC-6)
- 22. INSTALL FRONT FLOOR SILENCER SHEET (See page PC-10)
- 23. APPLYING ANTI-RUST AGENT
- (a) After applying the top coat layer, apply the anti-rust agent to the inside of the necked section structural weld spots.