SOUND QUALITY IS BAD IN ALL MODES (VOLUME IS TOO LOW)

INSPECTION PROCEDURE

1 ADJUST SOUND QUALITY

- (a) Adjust the sound quality.
 - (1) Operate the radio receiver assy to adjust the sound quality.

OK: Malfunction disappears.

OK SYSTEM IS OK

NG

2 | COMPARE IT WITH ANOTHER VEHICLE OF SAME MODEL

- (a) Compare it with another vehicle of the same model.
 - (1) Compare it with the vehicle of the same model which does not have a trouble to see if there is any difference in the sound quality.

OK: No difference is found.

OK > SYSTEM IS OK

NG

3 REPLACE STEREO COMPONENT AMPLIFIER ASSY (SEE PAGE 67–18)

HINT:

If the vehicle is not equipped with a stereo component amplifier assy (separate type), proceed to "NG".

(a) Replace the stereo component amplifier assy and recheck.

OK: Malfunction disappears.

OK > SYSTEM IS OK

NG

REPLACE RADIO RECEIVER ASSY (SEE PAGE 67-4)