
OIL PUMP ASSY (1MZ-FE) OVERHAUL

1705M 01

1. REMOVE OIL PUMP RELIEF VALVE

(a) Remove the plug, spring and relief valve.



2. INSPECT OIL PUMP RELIEF VALVE

- (a) Apply a light coat of engine oil.
- (b) Check that it falls smoothly into the valve hole by its own weight.


3. INSPECT OIL PUMP ASSY

- (a) Remove the oil pump cover.
 - (1) Remove the 10 screws and the oil pump cover.
- (b) Remove oil pump rotor set.

NOTICE:

Do not change the combination and install direction of the two rotors.

- (c) Inspect oil pump rotor set.
 - (1) Apply a light coat of engine oil to the oil pump rotor set and place them into the oil pump body. Check that the rotors revolve smoothly.




- d) Inspect rotor tip clearance.
 - (1) Using a feeler gauge, measure the clearance between the drive and driven rotor tips.

Standard tip clearance:

0.11 - 0.24 mm (0.0043 - 0.0094 in.)

Maximum tip clearance: 0.35 mm (0.0138 in.)




- (e) Inspect rotor body clearance.
 - (1) Using a feeler gauge, measure the clearance between the driven rotor and body.

Standard body clearance:

0.125 - 0.162 mm (0.0050 - 0.0064 in.)

Maximum body clearance: 0.30 mm (0.0118 in.)




- (f) Inspect rotor side clearance.
 - Using a feeler gauge and precision straight edge, measure the clearance between the rotors and precision straight edge.

Standard side clearance:

0.03 - 0.09 mm (0.0012 - 0.0035 in.)

Maximum side clearance: 0.15 mm (0.0059 in.)



- (g) Install oil pump rotor set.
 - (1) Apply a light coat of engine oil to the oil pump gear set and place it into pump body with the marks facing the pump body cover side.
- (h) Install oil pump cover.
 - (1) Install the 10 screws and oil pump cover.

Torque: 10 N·m (105 kgf·cm, 8 ft·lbf)

4. INSTALL OIL PUMP RELIEF VALVE

- (a) Apply a light coat of engine oil to the relief valve, and insert the relief valve and spring into the pump body hole.
- (b) Install the oil pump relief valve plug.

Torque: 24 N·m (245 kgf·cm, 18 ft·lbf)