## DTC C1223/43 ABS CONTROL SYSTEM MALFUNCTION

## **CIRCUIT** DESCRIPTION

DTC[No.	DTC[Detecting[Condition	Trouble[Area
C1223 <u>∏</u> [43	ABS[control[system]s[abnormal.	ABS[control[system

## INSPECTION PROCEDURE

|--|

A	Normal@ode
В	Malfunction[Code

B

REPAIR | CIRCUIT | INDICATED | BY OUTPUT CODE

Α

CHECK[ABS[WARNING[LIGHT[CIRCUIT