**DTC** 

## P1335/13 CRANKSHAFT POSITION SENSOR CIRCUIT MALFUNCTION(DURING ENGINE RUNNING)

## **CIRCUIT** DESCRIPTION

Refer[]o[DTC[P0335/12, 13[on[page[05-197.

DTC[No.	DTC[Detecting[Condition	Trouble[ <b>A</b> rea
P1335/13	If[conditions[a)]through[c)[are]met:  (a)[NE ≧ 1,000[pm  (b)[NE[signal[]s[not[detected[dor[over[50]]msec. (c)[Not[during[cranking	Open@r@hortin@rankshaft@position@ensor@ircuit Crank@position@ensor Crankshaft@position@ensor@late@No. 1 ECM

## WIRING DIAGRAM

Refer[10]DTC[P0335/12, 13[pn]page[05-197.

## INSPECTION PROCEDURE

Refer[]o[DTC[P0335/12, 13[on[page[05-197.

1[] INSPECT[\$ENSOR,[CRANK[POSITION

NG□

REPLACE[\$ENSOR,[CRANK[POSITION

OK

2∏ CHECK[HARNESS[AND]CONNECTOR(ECM-CRANK[POSITION[SENSOR)

NG[

REPAIR OR REPLACE HARNESS AND CONNECTOR

**OK** 

CHECK[\$ENSOR[ATTACHMENT[PART 3∏

NG□

REPAIR OR REPLACE SENSOR ATTACHMENT **PART** 

OK

CHECK[CRANKSHAFT[POSITION[SENSOR[PLATE[NO.1(TEETH[OF[SIGNAL 4∏ PLATE)

NG

**REPAIR** OR **REPLACE CRANKSHAFT POSITION SENSOR PLATE NO.1** 

OK

**CHECK AND REPLACE ECM**