

O : Parts Location

Code	See Page	Code	See Page	Code	See Page
I16	44	J7	43		

(: Ju

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2B	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)

: Connector Joining Wire Harness and Wire Harness

	Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
I	IE1	IE1 I 50 Instrument Panel Wire and Roof Wire (Inside of Front Left Pillar)	

: Ground Points

Code	See Page	Ground Points Location
IM	50	Instrument Panel Reinforcement RH