HOW TO PROCEED WITH TROUBLESHOOTING

05CCW-10

	nd-held tester can be used at steps 3, 6, 9, and 12.
1	VEHICLE BROUGHT TO WORKSHOP
NEXT	
2	CUSTOMER PROBLEM ANALYSIS (SEE PAGE 05–985)
NEXT	
3	CHECK AND CLEAR DTCS AND FREEZE FRAME DATA (SEE PAGE 05–1002 AND 05–1004)
NEXT	
4	PROBLEM SYMPTOM CONFIRMATION
	SYMPTOM DOES NOT OCCUR: GO TO STEP 5
	SYMPTOM OCCURS: GO TO STEP 6
5	SYMPTOM SIMULATION (SEE PAGE 01-32)
NEXT	
6	DTC CHECK (SEE PAGE 05–1002)
	THERE IS NO OUTPUT: GO TO STEP 7
	THERE IS OUTPUT: GO TO STEP 8
7	PROBLEM SYMPTOMS TABLE (SEE PAGE 05–997)
	CHECK FOR FLUID LEAKAGE AND GO TO STEP 10
8	DTC CHART (SEE PAGE 05–1010)
NEXT	
9	CIRCUIT INSPECTION (SEE PAGE 05–1013 TO 05–1101)
NEXT	
10	IDENTIFICATION OF PROBLEM
NEXT	

11	REPAIR	
NEXT		
12	CONFIRMATION TEST	
NEXT		
END		