Show operator card

Cue-list show over Wi-Fi. Print this and keep it next to the laptop.

Before doors open (about 5 minutes)

1. Power on everything: the control board, the 4 wall boards and the relay. Wait 10 seconds.
2. On the control computer, join Wi-Fi **LED-Control** (password **ledframes**). It will say "no internet": stay connected.
3. Open **http://192.168.4.1/** in Chrome or Edge.
4. Check the **Nodes** list: all 4 nodes show **online**. If one is offline, check its power, then the relay's power and cable. Do not continue until all 4 are online.
5. Switch to **Run** mode (top of the page), tab **Control**.
6. In the **Show** dropdown, pick the cue-list show. The big **GO** panel appears.
7. Wait until the panel says: **Ready. Nothing has played yet. · next section ready ✓**. The page is sending sections 1 and 2 to the nodes; this can take several seconds. **Do not press GO before this.**
8. Optional: in Edit mode, click a frame and press **Identify this frame** to check it lights up. Then switch back to Run mode.

> **Wi-Fi warning:** joining LED-Control disconnects this computer from every other Wi-Fi. If anything else on it needs its Wi-Fi during the show (remote access, a network control protocol, licensing), use a separate USB Wi-Fi adapter or another laptop just for LED-Control.

During the show

- **GO:** press **Space**, **Enter** or the **GO** button once per cue. A second press within 0.3 s is ignored on purpose.
- While a section plays, the page sends the next one to the nodes in the background. Press GO when the panel says **next section ready ✓**.
- If you press GO before it says ready, the page finishes sending first, then starts the cue. On a weak wall this can take a few seconds.
- If a message says **"N node(s) did not confirm the cue"**: press **GO** once more, then check the relay and the wall boards' power.
- Leave **5 to 10 seconds** between cues when you can, so the next section has time to arrive.

> **Do not, during the show:** click individual frames (they leave the cue list until Reset) · use Previous, Go to or Find nodes (they re-send programs) · reload the page (the next GO must re-send first) · edit programs, upload, or unplug anything.

If something goes wrong

What you see	What to do
A wall's frames did not change after GO	Press GO once more. Check the relay is powered.
A node shows offline	Its lights keep their last state. Check the node's power, then the relay's.
"Link lost, reconnecting"	It reconnects by itself. Check the laptop is still on LED-Control. Lights are not affected.

Everything seems frozen	The lights keep playing. Reconnect to Wi-Fi, reopen the page, and press GO for the next cue. The page remembers which section was playing.

After the show

- Press **Reset** (confirm). The next GO starts at section 1. Lights stay as they are; use **All off** to turn them off.

Safe if the radio fails: each wall board plays its own program and never turns its lights off when the radio drops. Only new commands (GO, edits) need the radio.