



Print a magazine from a web page. Designed with CSS print* for a one-off publication every time you print!







Using a CHROME browser go to this URL:

∆ https://objetpapier.fr/print-it



Enter the requested informations and click on PRINT





On the print window, adjust the settings like this:

Destination > choose your printer Pages > all

Copies > 1 Colors > Back and white



In the "more settings" menu:

Paper size > A4 Pages per sheet > 1 Margins > default Scale > default

Options > Check the "background graphics" checkbox



Load the 16 blank sheets in the printer and start printing by clicking on PRINT.





Fold each one of the sheets now printed following the dashed line.




printed faces outside



Cut the cover sheet in half following the dashed line. As well as the tape on the right side of the sheet n°2 on page 4.





Gathers the folded sheets between the two cover sheets then bind it together using the plastic binding rod included.

Tips 1 : you can help yourself with drawing clips to hold your pack. Tips 2: use the rounded corner of the rod to insert the sheets with ease.



Leave the silver sides of the cover and back-cover, following the mentions in the margins.



All done, reading time!





, (3)

INCLUDED IN THIS ISSUE:



Blank sheets (interior pages)



Printer page (cover pages)



Binding rod

WHAT YOU NEED:



Computer/Internet





Black cartridge



Scissors



Hands



Time