

How to run the project in Eclipse IDE


1. Download code from Github (https://github.com/oblu-iot/ObluScope-Java).




2. Unzip the ObluScope-Java-master.zip (e.g. "C:\Users\admin\Downloads\ObluScope-Java-master.zip").




3. Open the Eclipse IDE and click on File -> Open Project From File System...




- 4. Browse to unzip folder "C:\Users\admin\Downloads\ObluScope-Java-master folder".
 - Step 1: Click on **Directory** button.
 - Step 2: Navigate to folder "C:\Users\admin\Downloads\ObluScope-Java-master" folder.
 - Step 3: Click on OK button.




5. Select project "ObluScope-Java-master" and click on OK button.




6. Now project is imported. Right click on project and select **Properties**.



- 7. Follow below steps to link to RXTX native library.
 - Step 1: Select "Java Build Path".
 - Step 2: Select "Libraries" tab.
 - Step 3: Expand the "RxTxcomm.jar".
 - Step 4: Select "Native Library Location" under RxTxcomm.jar
 - Step 5: Click on **Edit** button. Dialog box "Native Library Configuration" will be popped up.



- 8. Set the RXTX native library path by following below mentioned steps
- Step 1: Set the **Location path** to RxTx native library folder e.g. C:\Users\admin\Downloads\ObluScope-Javamaster\lib\native.
 - Step 2: Click on **OK** button.
 - Step 3: Click on "Apply and Close" button on "Native Library Configuration" dialog box.



- 9. Connect your device (oblu) using USB cable.
- **10.** To find the serial port's name , refer the https://www.inertialelements.com/oblu/resources/how-to-find-serial-port.pdf
- **11.** Open **config.properties** and change the value of parameter **com.rotate.serialport** as you get in Step # 10. Change the data sampling frequency by changing the value of **com.rotate.outrate** but its value must be one of the following values.


250

125


62.5

31.25

15.625



12. Now run the project by right clicking on "ObluScope-Java-master" project, then select Run and choose Java Application.



13. Select "TwoWaySerialComm" from list and click on OK button.

