DCM

Runnable_SOH_RIDClearLogs

NvM

Normal behaviour

alt **[Previous write ongoing]**

OpStatus : DCM_INITIAL ; 0xFXXX

Check Write

NVM_REQ_OK

Clean & Write

NVM_REQ_OK

DCM_PENDING

OpStatus : DCM_PENDING ; 0xFXXX

Check Write

NVM_REQ_PENDING

DCM_PENDING

[No Write]

OpStatus : DCM_INITIAL ; 0xFXXX

Check Write

NVM_REQ_PENDING

DCM_E_GENERALPROGRAMMINGFAILURE

alt **[Write OK]**

OpStatus : DCM_PENDING ; 0xFXXX

Check Write

E_OK

E_OK

[Write fails]

OpStatus : DCM_PENDING ; 0xFXXX

Check Write

E_NOT_OK

DCM_E_GENERALPROGRAMMINGFAILURE

Invalid DID

OpStatus : DCM_INITIAL ; 0xF123

E_NOT_OK ; DCM_E_REQUESTOUTOFRANGE

Valid DID, monitor not configured

OpStatus : DCM_INITIAL ; 0xF08F

E_OK

DCM

Runnable_SOH_RIDClearLogs

NvM