
DIAG
SUSD
SOH
SSC
PNC
ERRH
RTE
WdgM
DCM
BswM
OS
DIAG_ECUResetRequest
DIAG_SOH_ProgrammingRequest
DIAG_SOH_GetMEC
BatteryVoltageRange<Min>To<Max>Port
SUSD_SOH_PermitExecution
SUSD_SOH_ResetOccurred
SSC_E_SecureMessageMonitoringEvents
SSC_SOH_SecurityAccessError
PNC_SUSD_ShutdownPermission
ERRH_E_BswEvent
ERRH_SOH_ClearDiagReq
OS_Protection_Error_Hook
DiagnosticReprogrammingRequest
SOH_BswM_Cry_SECP_Errors
BswM_SOH_ShutdownActionList
SOH_WdgM_IndividualMode<1..n>
WdgM_SupervisedEntity_SOH
SOH_WdgM_IndividualMode_Errh
DataServices<SOH>Data<n>