USER MANUAL

A 3-voice drum synthesizer with delay and effects. Designed for hands-on control and capable of both classic drum machine sounds and more experimental, abstract textures.

The device has three drum tracks, D1, D2, and D3, driven by a 16-step sequencer, plus one master channel. Each channel has eight knobs and includes wavefolder distortion, delay send, and volume controls, plus parameters specific to that voice.

This device uses a Boss-style 9-volt center-negative power supply.

D1: KICK

A synthesized kick voice. Tuned for classic kick drum sounds by default, but capable of a broad range of tonal and textural results well beyond typical drum use.

Frequency sets the pitch of the oscillator.
Decay controls the length of the sound.
Snap controls the transient click at the attack.
Oscillator Shape selects the waveform: sine, square, or sawtooth.
Body is an EQ that cuts mids for a punchier character.
Wavefolder Distortion adds harmonics and grit.
Delay Send controls how much signal feeds the delay line (pre-distortion).

D2: CLAP / SNARE

A synthesized snare or clap sound, with a mix knob to blend between the two.

Snare Body Frequency tunes the pitched component of the snare.
Decay sets the length of the tail.
Snare Noise adds white noise to simulate snare wires, ranging from tight to loose.
Voice Mix crossfades between snare and clap.
Reverb controls the reverb level, room size, and decay time on the snare/clap voice.
Wavefolder Distortion adds harmonic saturation.
Delay Send controls the delay feed (pre-distortion).

D3: HATS / PERCUSSION

Three sound models crossfaded with the voice knob: an FM metallic hat, a 606-style analog hat, and a percussion voice that ranges from a short click to a tonal ping depending on decay.

Tune sets the pitch across all three models.

Decay controls the length of the sound.

Accent Pattern selects from preset accent patterns that add dynamic variation to the sequence.

Voice crossfades between the three models (FM, 606, Perc).

Lowpass Filter controls the high end, useful for darkening hats.

Wavefolder Distortion adds edge and harmonic content.

Delay Send controls the delay feed (pre-distortion).

MASTER CHANNEL

Tempo (BPM) sets the sequencer speed from 60 to 300 BPM across most of the knob range. Past roughly 80%, the tempo jumps to 800–999 BPM for textural, noise-based territory.

Lowpass Filter controls the high end of the master bus with a slight resonance.

Choke is a global decay modifier: negative values tighten all voices, positive values loosen them.

Wavefolder Frequency sets the modulation rate of the master wavefolder.

Wavefolder Intensity sets the depth of the effect.

Delay Time sets the interval of the rhythmically synced delay line.

Master Volume controls the overall output level.

Delay Intensity blends feedback and wet level.

Each track's delay send is independent and pre-distortion.



SEQUENCER

Press **1**, **2**, or **3** to select which track to sequence. Toggle steps on or off with the 16 step buttons.

THE X BUTTON

X is a modifier key. Hold it in conjunction with other buttons to toggle modes, select memory slots, and change settings.

CHROMA MODE

CHROMA turns a drum voice into a step-sequenced synthesizer. Toggle it per-track by holding **X** and pressing **1**, **2**, **3**, or ▶ (for the master wavefolder).

When CHROMA is active, each step plays its own programmable note instead of the normal drum sound. To set the pitch of a step, hold the step button and turn that track's Frequency/Tune knob. Layer multiple CHROMA voices to build basslines, melodies, and tonal textures alongside or instead of the drum pattern.

When **D1 CHROMA** is active, the Body knob becomes a low-pass filter and the Snap knob becomes envelope filter amount.

Active CHROMA channels are indicated by squares at the bottom of the OLED display.

MONOBASS MODE

Hold **X** for several seconds to enter MONOBASS mode.

MONOBASS turns the step buttons into a live monophonic keyboard for D1. Twelve buttons become chromatic keys spanning one octave; the Frequency knob shifts octaves. D2 and D3 continue to play their sequences normally.

As in D1 CHROMA, the Body knob becomes a low-pass filter and the Snap knob becomes envelope filter amount. The oscilloscope remains visible on the OLED.

SHUFFLE

Shuffle is adapted from the TR-909 and has six levels. Hold **X** and press **Step 16** to cycle through those levels. Higher settings may sound better at slower tempos. A setting of 4 or 5 might sound best at 120 BPM.

MEMORY

The device has 10 memory slots. Hold **X** and press **Step 1 through 10** to select a slot, then use **SAVE** or **LOAD** to write or recall.

Each slot stores the drum pattern, CHROMA notes and mode state, and the shuffle setting.

QUICK REFERENCE

CONTROL LAYOUT

D1 (KICK)		D2 (CLAP/SNARE)		D3 (HATS/PERC)		MASTER	
Frequency	Volume	Snare Body Freq	Volume	Tune	Volume	Tempo (BPM)	Master Volume
Decay	Snap *(Envelope filter)*	Decay	Snare Noise	Decay	Accent Pattern	Lowpass Filter	Choke
Osc Shape	Body *(Resonant filter)*	Voice Mix	Reverb	Voice	Lowpass Filter	Wavefolder Freq	Wavefolder Intensity
Wavefolder	Delay Send	Wavefolder	Delay Send	Wavefolder	Delay Send	Delay Time	Delay Intensity

BUTTON COMBOS

ACTION	COMBO
Select memory slot	Hold X + Step 1 through 10
Toggle CHROMA (per voice)	Hold X + 1 / 2 / 3 / ▶
Set CHROMA step pitch	Hold step button + turn Frequency/Tune
Enter MONOBASS	Hold X (several seconds)
Change shuffle mode (0–6)	Hold X + Step 16
Set PPQN	Hold X + L

DISPLAY

The OLED shows a real-time oscilloscope waveform view along with current parameter values and mode indicators.

AUDIO OUTPUTS

1/4" line out, 1/8" line out, headphone out, and USB audio.

EXTERNAL CLOCK SYNC

The device accepts an external pulse clock input with configurable PPQN. When a clock is detected, the sequencer locks to it automatically. An armed count-in with beat countdown ensures tight sync from the first beat. Press ▶ on the first beat of the master device's sequence and your pattern will drop in after one measure.