

REVOGATE - How to Connect

(c) (r) All rights reserved Vorpco LDA

This guide explains how to connect to the Revogate controller using the local Wi-Fi access point and the web interface.

Quick connection details

Wi-Fi network	REVOGATE AP
Wi-Fi password	12345678
Preferred address	http://revogate.net
Fallback address	http://192.168.4.1

Step 1 - Power the controller

Connect power to the Revogate controller. Wait until the controller starts and the Wi-Fi access point becomes available.

Step 2 - Connect to the controller Wi-Fi

On your phone, tablet, or computer, open Wi-Fi settings and connect to:

SSID: REVOGATE AP
Password: 12345678

You can also scan the Wi-Fi QR code shown on the next page.

Step 3 - Open the control page

After connecting to the Revogate Wi-Fi network, open your browser and enter:

<http://revogate.net>

If the name does not open on a specific device, use the fallback address:

<http://192.168.4.1>

Step 4 - Connect Revogate to client Wi-Fi

In the CLIENT WI-FI section, choose the local client Wi-Fi network from the dropdown, type the password, and press CONNECT. The status indicator will show the connection state.

Status colors: red = off / not connected, yellow = connecting or saved network, green = connected.

Troubleshooting

If revogate.net does not open, confirm you are connected to the REVOGATE AP Wi-Fi. If needed, open <http://192.168.4.1> directly. If the expected client Wi-Fi network does not appear in the list, press SCAN again.

QR Codes

Use the first QR code to join the Revogate Wi-Fi network. Use the second QR code to open the local control page.

Connect to Wi-Fi	Open control page
	
SSID: REVOGATE AP Password: 12345678	http://revogate.net

Note: A standard Wi-Fi QR code connects the device to Wi-Fi. It does not always open the browser automatically. If the browser does not open by itself, scan the URL QR code or manually type <http://revogate.net>.