



## Hybrid Parity (Super) Inverter



## DATASHEET

### 3.6kW/5.5kW/8.8kW PLUS PARALLEL VERSION

SUNSYNK-8K-SG01LP1 SUNSYNK-5K-SG03LP1 SUNSYNK-8K-SG02LP1 SUNSYNK-7.6K-SG02LP1 SUNSYNK-6K-SG02LP1 SUNSYNK-5K-SG02LP1 SUNSYNK-3.6K-SG02LP1

Global Tech China Ltd, 3 Floor, Wai Yip Industrial Building, 171 Wai Yip Street,  
Kwun Tong, Kowloon, Hong Kong.

Tel: +852 2884 4318 Fax: +852 2884 4816

[www.sunsynk.com](http://www.sunsynk.com) / [sales@globaltech-china.com](mailto:sales@globaltech-china.com) / [www.globaltechhk.com](http://www.globaltechhk.com)

## Australian Manual

No country code is required since the unit is preset to the Australian standards

This inverter complies with IEC 62109-2 clause 13.9 for earth fault alarm monitoring. If an Earth Fault Alarm occurs, the fault code F24 will be displayed on the inverter screen /the LED indicator fault will light up.

All these models fall into two cabinet / PCB types 5.5kW (Small) and 8.8kW (Large):

### 5kW Type:

SUNSYNK-5K-SG02LP1  
SUNSYNK-3.6K-SG02LP1  
SUNSYNK-6K-SG02LP1  
SUNSYNK-5K-SG03LP1

### 8.8 kW Type

SUNSYNK-8K-SG01LP1  
SUNSYNK-8K-SG02LP1  
SUNSYNK-7.6K-SG02LP1



3.6kW / 5.5kW




8.8kW

## **Index**

<b>1. SYSTEM OVERVIEW.....</b>	<b>4</b>
<b>2. TECHNICAL SPECIFICATION .....</b>	<b>6</b>
<b>2.1. SYSTEM DIAGRAM .....</b>	<b>8</b>
<b>3. OPERATION.....</b>	<b>9</b>
<b>3.1. HOME PAGE .....</b>	<b>9</b>
<b>3.2. STATUS PAGE .....</b>	<b>10</b>
<b>3.3. SYSTEM FLOW PAGE .....</b>	<b>11</b>
<b>3.4. ADVANCED SETTINGS FOR PARALLELING INVERTERS .....</b>	<b>12</b>
<b>3.5. SOLAR POWER GENERATED .....</b>	<b>13</b>
<b>3.6. GRID POWER .....</b>	<b>14</b>

## 1. SYSTEM OVERVIEW



The Sunsynk Hybrid Parity Inverter is a highly efficient power management tool that allows the user to hit those ‘parity’ targets by managing power flow from multiple sources such as solar, main electrical grids, and generator, and then effectively storing and releasing electric power as the utilities require.

### INTERACTIVE

- Easy and simple to understand display
- Supporting Wi-Fi or GSM monitoring
- Visual power flow screen
- Built-in 2 strings of MPP trackers
- Smart settable 3-stage MPPT charging for optimized battery performance
- Auxiliary load function
- Parallel / multi invert function grid-tied and off-grid

### COMPATIBLE

- Compatible with main electrical grid voltages or power generators
- Compatible with wind turbines
- 220V single phase, pure sinewave inverter
- Self-consumption and feed-in to the grid
- Auto restart while AC is recovering
- Auto earth bond feature (Via a relay)

### CONFIGURABLE

- Fully programmable controller

- Programmable supply priority for battery or grid
- Programmable multiple operation modes: on-grid/off-grid & UPS
- Configurable battery charging - current/voltage based on applications by LCD setting
- Configurable AC / solar / generator charger priority by LCD setting

## **SECURE**

- Overload/over-temperature/short-circuit protection
- Smart battery charger design for optimized battery protection
- Limiting function installed to prevent excess power overflow to grid

## **APPLICATIONS**

- Marine (vessel power management)
- Power shedding (home/office/factory)
- UPS (fuel-saving systems)
- Remote locations with solar and wind generators
- Building sites
- Military locations
- Telecommunication

## 2. TECHNICAL SPECIFICATION

---

### ■ SUNSYNK-3.6K-SG02LP1 and SUNSYNK-5K-SG03LP1

Model	SUNSYNK-3.6K-SG02LP1	SUNSYNK-5K-SG03LP1
Battery Input Data		
Battery Type	Lead-acid or Lithium-ion	
Battery Voltage Range (V)	40~60V	
Max. Charging Current (A)	90A	120A
Max. Discharging Current (A)	90A	120A
Charging Curve	3 Stages/Equalisation	
External Temperature Sensor	Optional	
Charging Strategy for Li-Ion Battery	Self-Adaptation to BMS	
PV String Input Data		
Max. DC Input Power (W)	4680W	6500W
PV Input Voltage (V)	370V (100V~500V)	
MPPT Range (V)	125~425V	
Full Load DC Voltage Range (V)	240~425V	
Start-up Voltage (V)	150V	
PV Input Current (A)	11A+11A	
No. of MPPT Trackers	2	
No. of Strings Per MPPT Tracker	1+1	
AC Output Data		
Rated AC Output and UPS Power (W)	3600W	5000W
Max. AC Power (W)	3960W	5500W
Peak Power (off-grid)	2 times of rated power, 10 S	
AC Output Rated Current (A)	15.7A	21.7A
Max AC Output Current (A)	18A	25A
Max Continuous AC Passthrough (A)	35A	
Power Factor	0.8 leading to 0.8 lagging	
Output Frequency and Voltage	50/60Hz; 220/230/240Vac (single phase)	
Grid Type	Single Phase	
Current Harmonic Distortion	THD<3%(Linear load<1.5%)	
Efficiency		
Max. Efficiency	97.60%	
MPPT Efficiency	96.50%	
Euro Efficiency	99.90%	
Protection		
PV Input Lightning Protection	Integrated	
Anti-islanding Protection	Integrated	
PV String Input Reverse Polarity Protection	Integrated	
Insulation Resistor Detection	Integrated	
Residual Current Monitoring Unit	Integrated	
Output Over Current Protection	Integrated	
Output Shorted Protection	Integrated	
Output Over Voltage Protection	Integrated	
Certifications and Standards		
Grid Regulation	VDE 0126, AS4777, NRS2017, G98, G99, IEC61683, IEC62116, IEC61727, RD1699:2011, XP C15-712-3:2019-05	
Safety Regulation	IEC62109-1, IEC62109-2	
EMC	EN61000-6-1, EN61000-6-3	
General Data		
Operating Temperature Range (°C)	-25~60°C, >45°C Derating	
Cooling	Fan	
Noise (dB)	<30	



Communication with BMS	RS485; CAN
Weight (kg)	20.5
Size (Length x Width x Height)	580 x 330 x 208 mm
Protection Degree	IP65
Installation Style	Wall-mounted
Warranty	5 years
Maximum Altitude	4000 m

■ SUNSYNK-5K-SG02LP1, SUNSYNK-6K-SG02LP1, SUNSYNK-7.6K-SG02LP1, SUNSYNK-8K-SG01LP1, and SUNSYNK-8K-SG02LP1

Model	SUNSYNK-5K-SG02LP1	SUNSYNK-6K-SG02LP1	SUNSYNK-7.6K-SG02LP1	SUNSYNK-8K-SG01LP1/ SUNSYNK-8K-SG02LP1
<b>Battery Input Data</b>				
Battery Type			Lead-acid or Lithium-ion	
Battery Voltage Range (V)			40~60V	
Max. Charging Current (A)	120A	135A	190A	190A
Max. Discharging Current (A)	120A	135A	190A	190A
Charging Curve			3 Stages/Equalisation	
External Temperature Sensor			Optional	
Charging Strategy for Li-Ion Battery			Self-Adaptation to BMS	
<b>PV String Input Data</b>				
Max. DC Input Power (W)	6500W	7800W	9880W	10400W
PV Input Voltage (V)			370V (100V~500V)	
MPPT Range (V)			125~425V	
Start-up Voltage (V)			150V	
PV Input Current (A)	11A+11A	18A+9A	18A+18A	18A+18A
No. of MPPT Trackers			2	
No. of Strings Per MPPT Tracker	1+1	2+1	2+2	2+2
<b>AC Output Data</b>				
Rated AC Output and UPS Power (W)	5000W	6000W	7600W	8000W
Max. AC Power (W)	5500W	6600W	8360W	8800W
Peak Power (off-grid)			2 times of rated power, 10 S	
AC Output Rated Current (A)	20.8A	25A	31.7A/33A	33.4A/35A
Max AC Output Current (A)	24A	28.8A	36.4A/38A	38.3A/40A
Max Continuous AC Passthrough (A)	48A	80A	90A	90A
Output Frequency and Voltage			50/60Hz; 120/240Vac(split phase), 208Vac(2/3), 230Vac(single phase)	
Grid Type			Split phase, 2/3 phase, Single phase	
Current Harmonic Distortion			THD<3%(Linear load<1.5%)	
<b>Efficiency</b>				
Max. Efficiency			97.60%	
MPPT Efficiency			96.50%	
Euro Efficiency			99.90%	
<b>Protection</b>				
PV Arc Fault Detection			Integrated (Except European Type)	
PV Input Lightning Protection			Integrated	
Anti-islanding Protection			Integrated	
PV String Input Reverse Polarity Protection			Integrated	
Insulation Resistor Detection			Integrated	
Residual Current Monitoring Unit			Integrated	
Output Over Current Protection			Integrated	
Output Shorted Protection			Integrated	

Output Over Voltage Protection		Integrated
<b>Certifications and Standards</b>		
Grid Regulation		UL1741, IEEE1547, RULE21, VDE0126, AS4777, NRS2017, G98,G99, IEC61683, IEC62116, IEC61727
Safety Regulation		IEC62109-1, IEC62109-2
EMC		EN61000-6-1, EN61000-6-3, FCC 15 Class B
<b>General Data</b>		
Operating Temperature Range (°C)	-25~60°C, >45°C Derating	
Cooling	Fan	
Noise (dB)	<30	
Communication with BMS	RS485; CAN	
Weight (kg)	32	
Size (Length x Width x Height)	670 x 420 x 233 mm	
Protection Degree	IP65	
Installation Style	Wall-mounted	
Warranty	5 years	
Maximum Altitude	4000 m	


## 2.1. System Diagram



### 3. OPERATION

#### 3.1. Home Page

Press Esc button any page to access the home page:



Daily readings

Real time readings

#### What this page displays:

- Total daily power into the battery (kWh).
- Total daily power out of the battery (kWh).
- SOC (State of charge of the battery) (%).
- Total daily solar power produced in (kWh).
- Total hourly usage of the generator (Time).
- Total daily power sold to the grid (kWh).
- Total daily power bought from the grid (kWh).
- Real-time solar power in (kW).
- Real-time load power in (kW).

- Real-time battery charge power in (kW).
- Real-time grid power in (kW).
- Serial number.
- Time date.
- Fault condition.
- Access stats pages.
- Access status page.
- Access fault diagnostic page.

### 3.2. Status Page

To access the Status page, click on the “Battery” or “AC Load” dial on the Home page.

#### What this page displays:

- Total solar power produced.
- MPPT 1 power/voltage/current.
- MPPT 2 power/voltage/current.
- Grid power.
- Grid frequency.
- Grid voltage.
- Grid current.
- Inverter power.
- Inverter frequency.
- Inverter voltage.
- Inverter current.
- Load power.
- Load voltage.
- Battery power charge/discharge.
- Battery SOC.
- Battery voltage.
- Battery current.
- Battery temperature.

0 Watts 0.00 V 0.00 Amps 0.0 C	0 watts 0 Hz 0 Volts 0.0 Amps CT:0Watts LD: 0Watts	0 Watts 0.00 Volts 0.0 Amps
	<b>Battery</b>	<b>Grid Power</b>
0 watts 0 Hz 0 Volts 0.0 Amps DC:100.0 C AC:100.0 C	0 Watts 0.00 Volts 0.0 Amps	0 Watts 0.00 Volts 0.0 Amps
	<b>Inverter Power</b>	<b>Load Power</b>
		<b>Solar Power 1</b>
		<b>Solar Power 2</b>

**Solar Column:** Shows total PV power at the top and then details of each of the two MPPT's below L1 & L2 voltage.

**Grid Column:** Shows grid total power, frequency, voltage, and current. When selling to grid the power is negative. When receiving from the grid the power is positive. If the sign of the grid and HM powers are not the same when the PV is disconnected and the inverter is only taking energy from the grid and using the HM CT connected to Limit-2 then please reverse the polarity of the HM current sensor. **Important:** See section on CT coil.


**Inverter Column:** Showing inverter total power, frequency, L1, L2, voltage, current, and power.

**Load Column:** Showing total load power, load voltage, and power on L1 and L2.

**Battery Column:** Showing total power from the battery, battery SOC, battery voltage, battery current (negative means charge, positive means discharge) battery temperature (shows zero if the battery temperature sensor is not connected). DC transformer temperature and AC heatsink temperature (When the temperature reaches 90°C it will show in red and start deteriorating when it reaches 110°C. Next, the inverter will shut down to allow it to cool and reduce its temperature).


### 3.3. System Flow Page

Access by clicking on the “Bar Chart ” on the home page




To better understand the functioning of your system, take a look at the figure bellow:

1. The PV modules charge the batteries.
2. When the batteries reach a specific level (programmable) the battery power is fed into the inverter.
3. The inverter can then supply power to the grid (export or no export), load, and auxiliary or smart load.
4. CT coil controls the export power.



### 3.4. Advanced Settings for Paralleling Inverters

To configure multi-inverter settings click on the “Advance” icon.



#### What this page displays:

- If the inverter operates as a master or a slave.
- Modbus Device ID, which must be unique for each inverter connected to the bus/wire.


#### What you can do from this page:

- Set the inverter as a master or slave per bus/wire.
- Set the phase in which the inverter will be paralleled.
- Set the Modbus SN for paralleling.

The Sunsynk parity inverter can be wired standalone or where more power is required it can be connected in parallel either single or 3 phase configuration. The maximum number of inverters that can be paralleled in a single phase utility grid is three (10.8kW, 16.5kW, and 26.4kW for the 3.6kW, 5.5kW, and 8.8 kW model, respectively) and the maximum number that can be paralleled in a three phase utility grid is nine (32.4kW, 49.5kW, and 79.2kW for the 3.6kW, 5.5kW, and 8.8 kW model, respectively).

To parallel six inverters in a three phase utility grid is necessary to set three inverters as master and three as slaves:

- Phase A: Master A and Slave A
- Phase B: Master B and Slave B
- Phase C: Master C and Slave C







For stability, all the batteries need to be connected in parallel. It is recommended a minimum cable size of 50mm diameter with fuse isolators to each inverter.

Each invert will require a fuse isolator with surge protection and each group circuit will require an RCD. If the batteries are supplying power to the main load during the outage then a change over switch will also be required or a split load can be used.

### **3.5. Solar Power Generated**


This page shows the daily, monthly, yearly, and total solar power produced. Access this page by clicking on the “Solar/Turbine” icon on the home page.




### 3.6. Grid Power

This page shows the daily, monthly, yearly, and total grid power export or consumed. Access this page by clicking on the “Solar/Turbine” icon on the home page.

Return	Day	Month	Year	Total
--------	-----	-------	------	-------




Return	Day	Month	Year	Total
--------	-----	-------	------	-------



Grid Power Import / Export :- Day


Grid Power Import / Export :- Month

Return	Day	Month	Year	Total
--------	-----	-------	------	-------



Grid Power Import / Export :- Year

Return	Day	Month	Year	Total
--------	-----	-------	------	-------



System Grid Power: Total

**Australia Main Dealer**

HORTON SOLAR CONSULTING Pty. Ltd  
166a King William Road  
HYDE PARK SA 5061  
+61(0)429 075 444  
Website <http://www.sunsynk.com>  
Contact [leigh\\_horton@pm.me](mailto:leigh_horton@pm.me)

**Manufacturer**

Sunsynk Limited ( Part of Global Tech )  
171 Wai Yip Street  
Kwun Tong  
Kowloon  
Tel: +852 2884 4318 Fax: +852 2884 4816  
Website <http://www.sunsynk.com>  
Contact [Info@Globaltech-china.com](mailto:Info@Globaltech-china.com)