

### **188A Stoplight Voltage Tester**

Tested upon receipt, before and after each use, once a week on 193A Test Plug, after you change battery with 193A Test Plug and once a month with 193A Test Plug signing off with foreman on 6A Card, If dropped test on 1188A Test Set and once a year with Foreman on 1188A Test Set which checks the 188A's Dielectric Strength of the test units housing and subjects it to 30,000 volts AC across the DC ground post, energizing the metal tube inside exposing any leaks over 50 volts from the housing of the unit

**Voltage Ranges** DC 6 volts - 2,000 volts AC 50 volts - 20,000 volts 60 Hz

#### **The 188A Test Set Performs Two Functions:**

**It protects the user while conducting tests for potentially dangerous voltages**

**It indicates the presence of potentially hazardous voltages.**

- Should the 188A begin to vibrate hiss or buzz or red light flash, immediately move away
- Stored in green canvas bag with WIBU and B-Temporary Bond

**USED TO CHECK** - Trailers, mobile homes, ground rods, manhole covers, lead cables, poles, pole steps, guy wires, U-Guards, risers, cable sheaths, pedestals, homes or buildings covered with metallic/aluminum siding, suspended ceilings, street lights, strands, CATV, or Anything that you think could be energized.

#### **PARTS**

##### **Carbon Impregnated Cap**

- Protects tip from damage and Me from the tip.
- Provides attachment knob for WIBU cord to draw off induced voltage
- Cap is carbon impregnated to make cap conductive. Cap is not carbon coated
- Carbon could wear off and become non-conductive, would not draw off induced voltage.

**Carbide Tip** - Sharp to penetrate rust or paint

##### **Two LED's**

(Light Emitting Diodes)

**GREEN** - SAFE Absence of potentially hazardous voltage

**RED** -HAZARD Indicates potentially hazardous voltage.

##### **Check Contact**

- Left Side of test unit
- Checks internal circuitry/operation of 188A
- **Self Check** by holding cap to carbide tip and touching thumb to screw , you will get a flashing RED Light if 188A is working properly.

**DC Ground Post** - Right Side of test unit

- Used with B-Temporary Bond, grounding unit so you can test for DC Voltage.

**INSIDE 188A Test Unit** - TWIST TO OPEN

**O Ring** - Rubber gasket to keep out moisture.

**Battery** - Both use 9 Volt Eveready Alkaline Battery

- AT&T uses a #522A which fits into tube better.

**Housing** - **MUST MATCH CLIP!!** - Gold CTC ( Fluke C9970 )/ Silver Western Electric

**CLOSE UP 188A AND SELF CHECK**