



Client Site Technician Guide

Public RVM & Enterprise PecoDrop

Daily inspection, approved controls, first-line recovery and escalation

CLIENT TECHNICAL PERSONNEL

Manufactured by ISP Environmental Solutions Pvt. Ltd.

Edition 2026 • Controlled Service Document

1. Purpose and permitted work

This guide is for trained client personnel responsible for opening checks, cleaning, bin servicing, basic recovery, approved demonstrations and reporting faults. It covers both ISP machine families without mixing their material paths or workflows.

Public RVM
Installed at malls, transit stations and public locations. Accepts **plastic bottles, beverage cans and UBC/Tetra Pak cartons**; rejected objects use the reject path. Sessions may provide wallet, mobile-load or coupon rewards.

Enterprise PecoDrop
Corporate dual-display kiosk with QR scanner and keypad. Its apertures are  **magenta plastic**,  **green metal/cans** and  **cyan weighed office paper**.

Stop-work boundary: Do not open electrical panels, bypass interlocks, work near moving gates, change wiring/serial ports, upload firmware or use manufacturer servo-test codes. Isolate power and contact ISP when physical access to an actuator or energized compartment is required.

Before touching the kiosk

☐	Floor is dry, machine is stable, vents and emergency access are clear.
☐	No person, hand or object is inside an intake aperture or discharge path.
☐	Bins are installed correctly and are not overfilled.
☐	Displays, scanner/keypad, intake openings and visible cables are undamaged.
☐	Record machine ID, location, date/time and the exact on-screen message before recovery.

2. Approved operational codes

Enter a numeric sequence on the physical keyboard/keypad as one uninterrupted buffer sequence. Do not add spaces. Use only when the screen is responsive and all intake paths are clear.

Code/key	Availability	Approved client purpose
0	RVM & PecoDrop	Wake/start the customer session from idle mode.
Enter	RVM & PecoDrop	Finish the active session and proceed to reward/summary where applicable.
111	RVM & PecoDrop	Open the authorized administrator login. Credentials are still required.
888	RVM & PecoDrop	Open the telemetry/diagnostic view for reading and ISP fault reporting.
33	RVM & PecoDrop	Request manual chamber clearing only after visually confirming that no hand or loose object is in the mechanism.
1122	RVM & PecoDrop	Enter Demo Mode and open the demo-testing simulator for authorized training.
1218	RVM & PecoDrop	Open the system restart confirmation dialog. Confirm only after ending any customer session.
1219	RVM & PecoDrop	Open the system shutdown confirmation dialog. Use for a planned power-down.

Keyboard-only shortcuts: **S** stops a session and **A** opens administrator login on both apps. On PecoDrop, **F2** or **D** opens demo testing. These are for an attached service keyboard and should not be exposed during normal public use.

Do not use Esc as routine shutdown. It can close the kiosk application after diagnostics are recorded. Use **1218** for restart or **1219** for controlled shutdown.

3. PecoDrop-only client controls

These codes apply only to the enterprise PecoDrop dual-display system. Never enter them on a public RVM expecting the same action.

Code	Function	Safe use
66	Start machine operation	Use after the app is ready, calibration is complete and all three paths are clear.
77	Stop machine operation	Use before permitted cleaning/bin service or when abnormal behavior is observed.
88	Reset machine state	Use once after clearing the reported condition. Do not repeatedly reset a recurring fault.
99	Request calibration	Keep apertures empty and bins correctly seated until calibration confirms completion.
0012	Hardware kiosk left; video signage right	Restore this layout when the physical installation is wired in this orientation.
0021	Video signage left; hardware kiosk right	Use for the opposite physical display orientation.

Manufacturer-only controls: PecoDrop actuator/servo test codes **601–612** are intentionally not provided in this client guide. They can move iris and drop gates independently of normal intake. Only ISP manufacturer technicians may use them under a controlled service procedure.

PecoDrop calibration/start sequence

1. Confirm plastic, metal and paper apertures are empty; fit all bins correctly.
2. Start the PecoDrop application and allow the controller to reconnect.
3. If calibration is not automatically confirmed, enter **99** once.
4. Wait for a successful calibration/ready indication. Do not insert test material while calibration is running.
5. Enter **66**, then perform one supervised test for each enabled material path.

4. Opening, cleaning and bin service

Daily opening procedure

1. Inspect the enclosure, floor, plugs, visible cables, intakes and bins.
2. Power on approved external equipment, then the kiosk computer/machine according to the site procedure.
3. Confirm the correct application opens full-screen and the correct machine identity appears.
4. For PecoDrop, verify both landscape displays and their assigned roles; correct them with **0012** or **0021** if necessary.
5. Check network status and open telemetry with **888** if any connection indicator is abnormal.
6. Run one clean, valid sample per material path. Remove all samples from bins afterward if site policy requires it.

Cleaning and emptying

- End the active session. On PecoDrop, use **77** before permitted bin service.
- Use a dry microfiber cloth on screens and scanner glass. Apply cleaner to the cloth, never directly to electronics.
- Do not push tools through an aperture or force any gate. Do not spray water or solvent inside the machine.
- Empty and refit bins without disturbing sensors, wiring or load-cell platforms. PecoDrop paper weighing surfaces must remain free of trapped material.
- Close and latch all client-access doors; then restore operation and perform a supervised test.

Paper handling: PecoDrop office paper is measured by weight. Do not lean on, store tools on or manually press the paper platform; this can corrupt the zero/calibration reference.

5. First-line fault recovery

Observed condition	Client action	Escalate when
Screen idle or session will not begin	Press 0 . Confirm app and network status. If frozen, record evidence and use 1218 .	The app does not return after restart or repeatedly freezes.
Item remains in chamber	Stop new users, visually check the path, and use 33 once only when the path is clear of people.	The item remains, gate sounds abnormal, or manual access would be required.
Bin full message	End the session, empty/reseat the correct bin, remove loose material around the permitted area, then test.	The warning remains with an empty correctly seated bin.
PecoDrop not ready after startup	Confirm all three paths are empty; enter 99 once and wait for calibration.	Calibration fails, times out or reports the same full condition repeatedly.
Wrong PecoDrop display arrangement	Use 0012 or 0021 to match the physical left/right arrangement.	A display is missing, flickering or not detected.
Network/reward service unavailable	Open 888 , record status, keep the kiosk out of paid/reward operation if confirmation cannot be issued.	Connectivity persists after the site network is confirmed operational.
Unusual noise, smoke, odor, heat or repeated movement	Stop use, keep people away and perform the site's approved electrical isolation.	Immediately—do not restart or test.

Controlled restart

1. End the user session and record the fault.
2. Confirm all intake paths are clear.
3. Enter **1218** and select **Yes** in the confirmation dialog.
4. Allow the application and controller to recover without repeated key presses.
5. Verify ready state and complete a supervised material test.

Controlled shutdown

1. End the session, stop public access and complete bin/service records.
2. Enter **1219** and select **Yes**.
3. Wait until Windows and the computer are fully off before switching approved external power.

6. Demo and training use

1. Place the kiosk out of public service and ensure no real user session is active.
2. Enter **1122**. Confirm the Demo Mode indicator/testing window appears.
3. Use only the simulator functions needed for the training scenario. Demo events are not proof of physical sensor or payout operation.
4. Close demo testing, restart the kiosk with **1218** if required by site procedure, and verify normal mode before public use.

Never leave Demo Mode available to customers. Do not use simulated acceptance to certify hardware repair.

7. Information required for ISP support

Send one complete fault package. Accurate evidence is faster and safer than repeated resets.

☐	Machine ID, machine type (RVM or PecoDrop), client/site and exact location.
☐	Date/time, operator name and whether a customer session/reward was active.
☐	Exact screen message plus clear photos/video of the symptom; do not include customer personal data.
☐	Telemetry/status shown through 888 and current network condition.
☐	Material/path involved and the last successful operation.
☐	Actions already taken, in order, including codes used and restart outcome.
☐	Any noise, odor, heat, liquid ingress, impact damage or power event.

8. Return-to-service authorization

☐	No exposed wiring, liquid, heat, odor, structural damage or unsafe movement.
☐	All client-access doors/bins are correctly installed and secured.
☐	Application is full-screen, machine identity is correct and telemetry is normal.
☐	PecoDrop calibration is confirmed; both displays and all three material identities are correct.
☐	Each enabled intake passes one supervised valid test and rejects an unsuitable test item correctly.
☐	Session completes correctly and any reward flow is confirmed or intentionally disabled.
☐	Fault and corrective action are entered in the site log.

Machine ID		Site	
Technician		Date/time	
Result	☐ Returned to service ☐ Isolated / ISP escalation raised		
Signature			

Safe rule: If the cause is unknown or the fault returns after one controlled recovery, keep the machine out of service and escalate to ISP. Do not repeatedly reset, calibrate or restart it.