

TCP-IP Configuration User Guide

1. Run UHF Demo

The interface is as follows:

The screenshot displays the 'Function Configuration' tab of the TCP-IP Configuration User Guide interface. The interface is divided into several sections:

- Reader Setup:** Includes a 'Refresh' button, a 'NetCard' dropdown menu, a 'Search' button, and a 'Device : 0' field with a 'Clear' button.
- Current NetCard:** A table with columns: #, DeviceName, DeviceIp, DeviceMac, ChipVer, PcMac. The table is currently empty.
- Basic Setting:** Includes fields for 'Device Mac', 'DevName (21)', 'dhcpEn' (checkbox), 'Ip', 'Mask', 'Gateway', and 'com negotiation: omCfgEn' (checkbox). Below these are buttons: 'Get', 'Save', 'Default', 'Reset', 'Load', and 'Store'.
- Port_1 Heartbeat Detect:** Includes a 'port1_En' checkbox, 'NetMode' dropdown (set to 'TCP_SERVER'), 'LocalPort' field (set to 'randEn' and '0'), 'DomainEn' checkbox, 'DNS domain' field, 'Des IP/Port' field, 'BaudRate' dropdown (set to 'B300'), 'DataSize' dropdown (set to 'Bits5'), 'StopBits' dropdown (set to 'None'), 'Parity' dropdown (set to 'Odd'), 'PhyLst' dropdown (set to 'CloseSocketEn'), 'RxLen' field (set to '<=1024'), 'RxTimeout' field (set to '(10ms)'), 'ResetCtrl' dropdown (set to 'ClearBufferEn'), 'ReconnectCnt' field, 'DNS host' field, and 'DNS port' field.
- Note:** A section with two notes: (1) If you need to configure Client, please use a private network tool. (2) The old Neport interface cannot be searched for the moment. [Old tool link](#)
- Operation History:** A checkbox for 'Auto Clear'.
- Activate Serial Port Monitor:** A checkbox.

Please keep the DIP switch 3 & 4 On, as shown below:



Attention:

For searching the device easily, please keep the device connect with computer directly.

2. Search Device

Reader Setup | 18000-6C Tag Test | Serial Port Monitor | **NetPort Setup** | Function Configuration

Refresh NetCard Realtek PCIe GBE Family Controller

Search The total number of devices: 1 Clear

Current NetCard
ip:192.168.2.19, mask: 255.255.255.0, mac: 7C:B5:9B:58:FF:B1

#	DeviceName	DeviceIp	DeviceMac	ChipVer	PcMac
1	RoNetPort	192.168.0.178	38:3B:28:EB:D7:19	0	00:00:00:00:00:00

Basic Setting

Device Mac:

DevName (21):

dhcpEn: ☐

Ip:

Mask:

Gateway:

com negotiation: omCfgEn ☐

Get Save Default

Reset Load Store

Note

(1) If you need to configure Client, please use a private network tool

(2) The old Netport interface cannot be searched for the moment. [Old tool link](#)

Note:

- (1) Default configuration is: IP 192.168.0.178; Port number 4001; Work mode Server.
- (2) If you click Factory reset, the IP address will become 192.168.1.200, and the port number is random. you need to double click the devicename and click the "Default" button and then click the "Save" button.

3. View and Set

Search the device and get the parameters as follows:

Reader Setup | 18000-BC Tag Test | Serial Port Monitor | **NetPort Setup** | Function Configuration

Refresh NetCard: Realtek PCIe GBE Family Controller

Search The total number of devices: 1 Clear

Current NetCard
ip:192.168.2.19, mask: 255.255.255.0, mac: 7C:B5:9B:58:FF:B1

#	DeviceName	DeviceIp	DeviceMac	ChipVer	PcMac
1	RoNetPort	192.168.0.178	38:3B:26:EB:D7:19	0	00:00:00:00:00:00

double click

Basic Setting

Device Mac: 38:3B:26:EB:D7:19

DevName (21 RoNetPort)

dhcpEn: ☐

Ip: 192.168.0.178

Mask: 255.255.255.0

Gateway: 192.168.0.1

com negotiation: omCfgEn ☐

Get Save Default

Reset Load Store

Port_1 Heartbeat Detect

port1_En ☒

NetMode: TCP_SERVER

LocalPort: randEn ☐ 4001

DomainEn ☐

DNS domain

Des IP/Port: 192.168.0.200 1000

BaudRate: B115200

DataSize: Bits8

StopBits: One

Parity: None

PhyLost: CloseSocketEn ☐

RxLen: 1024 (<=1024)

RxTimeout: 0 (10ms)

ResetCtrl: ClearBufferEn ☒

ReconnectCnt: 0

DNS host: 0.0.0.0

DNS port: 0

Note

(1) If you need to configure Client, please use a private network tool

(2) The old Netport interface cannot be searched for the moment. [Old tool link](#)

Operation History: ☒ Auto Clear ☐ Activate Serial Port Monitor

Information as below:

Parameter	Remark
Device Name	ro board
IP	192.168.0.178
Subnet Mask	255.255.255.0
Gateway	192.168.0.1
Network Mode	Server
local port	Default: 4001. Pleas do not tick random port number.
Serial port baud rate	115200(Default and Recommended)

User can change the configuration by modifying the parameters:

Get Save Default

Reset Load Store

Parity: None

PhyLost: CloseSocketEn ☐

RxLen: 1024 (<=1024)

RxTimeout: 0 (10ms)

ResetCtrl: ClearBufferEn ☒

Save/Default Successful

NetPort configuration Settings or restore default success

Attention:

If the reader is connected via TCP/IP, please follow those steps:

- Ensure that an Ethernet Card has been installed in the PC.
- Ensure that PC and reader in the same network segment.