

Copyright Anders E E Wallin, 2020.



This documentation describes Open Hardware and is licensed under the CERN OHL v. 1.2. You may redistribute and modify this documentation under the terms of the CERN OHL v.1.2. (<http://ohwr.org/cernohl>). This documentation is distributed WITHOUT ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING OF MERCHANTABILITY, SATISFACTORY QUALITY AND FITNESS FOR A PARTICULAR PURPOSE. Please see the CERN OHL v.1.2 for applicable conditions

See SFP document
INF-8074.PDF
INF-8074i Specification for
SFP (Small Formfactor Pluggable) Transceiver

TX_FAULT:
should be pulled up with a 4.7K - 10K resistor on the host board.
Pull up voltage between 2.0V and VccT, R+0.3V. When high, output
indicates a laser fault of some kind. Low indicates normal
operation. In the lowstate, the output will be pulled to < 0.8V.

TX_DISABLE
Low (0 - 0.8V): Transmitter on
(>0.8, < 2.0V): Undefined
High (2.0 - 3.465V): Transmitter Disabled
Open: Transmitter Disabled

Use external DC-power or USB-plug power



1st PCB-run 2018-11-25

Anders.e.e.Wallin "at" gmail.com

Sheet: /

File: working.kicad_sch

Title: SFP Breakout Board

Size: A4

Date:

KiCad E.D.A. kicad-cli 7.0.6-7.0.6-ubuntu22.04.1

Rev: 2018.11

Id: 1/1