Parametersパネルを開く Set Scale Factorを 0.005 に設定 Scale Mode で offを選択 Glyph TypeでArrowを選択 Properties Display Information Apply Reset | Delete Scalars p U Vectors Glyph Type Arrow -⊟-Arrow Tip Resolution 6 Tip Radius 0.1 Tip Length 0.35 Shaft Resolution = Shaft Radius 0.03 Orient Scale Mode off 0.005 Set Scale Factor × Edit Maximum Number 5000 of Points ■ Mask Points Random Mode