

Step 1: Remove the cover

Loosen the four screws, lift the cover straight up.

Step 2: Clean the seal

Wipe the groove with a lint-free cloth and IPA.

Step 3: Torque the cover

12 Nm, crosswise, in two passes.