

Firing a load

1. Check the load is on its shelves.
2. Close the door and set the programme.