## SPARE PARTS / Parrot Disco / Servomotors


To replace the servomotors of the Parrot Disco, you need


a PH2 screwdriver, a T6 screwdriver and a T10 screwdriver.


It is recommended to use the Parrot Toolbox for this operation.





Parrot











remove them.

