This menu contains optional facilities that can be loaded.

This menu contains commands to manually move the robot.

Click here to quit.

Press here to load a server.

Press here to load a robot driver.

Press here to load a robot brain.

Brain Functions: Use these to start, stop, or step through a brain program.

Command Line: Interactive Pyro commands can be entered here.

Displays the loaded simulator. Clicking on it will open the file in the EMACS editor.

Shows the current robot platform. Clicking on it will open the file in the EMACS editor.

Name of the robot brain program. Clicking on it will open the file in EMACS.

Displays the current position and orientation of the robot.

Pyro Console: All messages are displayed here.

pyrobot@polka.brynmawr.edu

File   Window   Load   Robot   Brain   Help

Server:

Robot: View

Brain: View

Step   Run   Stop   Reload Brain

Pose:

Pyrobot Version 4.1.6: Ready...

Command: