How to Move Parts

Click & drag at the centre of the part to move it.

Press R or SPACE on your keyboard to rotate the part.

Click on the text above a part to move the silkscreen printing.

The blue lines connecting the parts are **ratlines**. They show where parts connect. Try to make sure none of them are crossing!







