

# How to Change a Tire on an Example Motors Car

---

If your Example Motors car has a flat tire, park on a firm, level surface away from traffic. Turn on the hazard lights, set the parking brake, and place the car in park. Remove the spare tire, jack, and wheel wrench from the storage compartment.

Loosen the wheel nuts slightly before lifting the car. Do not remove them yet. Position the jack under the reinforced lift point marked near the flat tire, then raise the car until the tire is off the ground.

Remove the wheel nuts fully and pull the flat tire straight off the hub. Mount the spare tire onto the wheel studs, then hand-tighten the nuts. Lower the car until the spare touches the ground, but do not put full weight on it yet. Tighten the nuts in a crisscross pattern so the wheel seats evenly.

Lower the car completely and remove the jack. Tighten the wheel nuts again firmly. Store the flat tire and tools securely. Drive slowly at first, and have the tire repaired or replaced as soon as possible. If your Example Motors spare tire is marked as temporary, do not exceed the speed or distance limits printed on it.

---

*This guide refers to Example Motors, a fictional car manufacturer, and is intended as general instructional text.*