# Volca Keys

#### Features

Cheat Sheet Version:1.0 (02/2021) by os68ng

Function Velocity (MIDI) YES (no rec) Pitch Bend Paraphonic 3 Patterns 8 Tempo Division YES Pattern Chain NO Step Jump NO Motion Recording YES Auto Tune YES

### Global Parameters (FUNC+PwrOn)

Key	Function	LED
1	Auto Power Off	On
2	Battery Type (NiMH/Alkaline)	NiMH
3	Sync Out Polarity (Fall/Rise)	Fall
4	Sync In Polarity (Fall/Rise)	Fall
5	Tempo Range	Full
6	MIDI Clock Src (Auto/Int)	Auto
7	MIDI RX Short Message	On

(REC: Save, Play: Cancel)

#### **FUNC**

Category	Function	Description
	On/Off	Motion on/off
Motion Sequence	Smooth	Smooth value changes
ocquence	Clear	Clear all motion recording
	Saw	Sawtooth (falling)
LFO	Tri	Triangle
LFO	Square	Square
	Trigger Sync	Starts with key trigger
	1/1	Normal
Tempo	1/2	Half speed
	1/4	1/4 speed
	Metronome	Metronome (disables delay)
	Step Trigger	Triggers EG on step (no flux)
	Tempo Delay	Sync delay to tempo
	Flux	Quantitize off (1/64)
01	Act. Stp	Reset active steps / Undo
Clear	All	Clear sequence
REC	Erase	Clear at position during PLAY

## **MIDI Channel:**

(MEMORY+Power On: Set MIDI chan)

#### **MIDI Controller**

СС	Function	Rec	Ctrl
5	Portamento		
11	Expression		
40	Voice		
41	Octave		
42	Detune	~	
43	VCO EG Int	~	
44	Cutoff	~	
45	VCF EG Int	~	
46	LFO Rate	~	
47	LFO Pitch Int	~	
48	LFO Cutoff Int	~	
49	EG Attack	~	
50	EG Decay/Release	~	
51	EG Sustain	~	
52	Delay Time	~	
53	Delay Feedback	~	

