SCSIMsgOut Page 1

SCSIMsgOut Send a message to the SCSI device

#include <<u>SCSI.h</u>> <u>SCSI Manager</u>

OSErr SCSIMsgOut(message);

<u>short</u> *message; Message value as defined by ANSI's SCSI

documentation

returns 16-bit Error Code; 0=no error

SCSIMsgOut sends a message to the external drive.

*message is an ANSI-defined value in the low-order byte of the message parameter.

Returns: an error code indicating success or failure of the function. It will be one of:

noErr (0) No error

scArbNBErr (3) Arbitration failure during SCSIGet; bus busy

scMgrBusyErr (7) SCSI Manager already occupied when SCSIGet was called

scSequenceErr (8) Operation out of sequence

scBusTOErr (9)

Bus timeout before data ready on blind read or write scComplPhaseErr (10)

Bus not Out Status phase; SCSIComplete call failed

Notes: Message values are listed in SCSI documentation from the American National Standards Institute.