SReadDrvrName Page 1

SReadDrvrName Read the name of the sResource for this slot and list ID

#include <<u>Slots.h</u>> <u>Slot Manager</u>

OSErr SReadDrvrName(spBlkPtr);

<u>SpBlockPtr</u> spBlkPtr; address of 56-byte <u>Slot Parameter Block</u>

structure

returns Error Code; 0=no error

SReadDrvrName reads the name of the sResource corresponding to the slot number and list identification number.

spBlkPtr is the address of a 56-byte **Slot Parameter Block** structure. The relevant fields are as follows:

Out-In Name		<u>Type</u>	Size Offset		<u>Description</u>
\rightarrow	spResult	<u>long</u>	4	0	FUNCTION result
\rightarrow	spSlot	<u>char</u>	1	49	Slot number
\rightarrow	spID	<u>char</u>	1	50	sResource list ID

Other parameters affected are:

```
spsPointer Ptr 4 4 Structure pointer spSize long 4 8 Size of structure
```

Returns: an operating system Error Code. It will be one of:

```
noErr (0)
                           No error
   smEmptySlot (-300)
                           No card in slot.
      smCRCFail (-301)
                           CRC check failed.
   smFormatErr (-302)
                           FHeader format is not Apple's
                           The revision of the card's declaration ROM is wrong.
  smRevisionErr (-303)
       smNoDir (-304)
                           Directory offset is NIL
                           The SDM could not allocate memory for the sInfo
smNosInfoArray (-306)
                           A reserved field of the declaration ROM was used.
    smResrvErr (-307)
  smUnExBusErr (-308)
                           An unexpected bus error occurred.
   smBLFieldBad (-309)
                           A valid ByteLanes field was not found.
 smDisposePErr (-312)
                           An error occurred during execution of DisposPointer.
smNoBoardSRsrc (-313)
                           There is no board sResource.
    smGetPRErr (-314)
                           Error during execution of sGetPRAMRec.
   smNoBoardId (-315)
                           There is no board ID.
 smInitStatVErr (-316)
                           The InitStatus_V field was negative after Primary or
                           Secondary Init.
  smInitTblVErr (-317)
                           Error while trying to initialize the sResource Table.
    smNoJmpTbl (-318)
                           Slot Manager jump table could not be created
  smBadBoardId (-319)
                           Board ID was wrong; reinit the PRAM record
```

Notes: The trap macro **SReadDrvrName** reads the name of the sResource corresponding to the slot number, <u>spSlot</u>, and sResource list identification number, <u>spID</u>, prefixes a period to the value of the cString and converts its type to <u>Str255</u>. It then reads the result into a Pascal string variable declared by the calling program and pointed to by <u>spResult</u>. The final driver name is compatible with the Open routine.