

Product Data Sheet

ITC-11-20

	F _x	F _y	F _z	M _z	M _y	M _x
Rated Load (N, N•m)	2500	2500	5000	4000	2000	2000
Overload Factor (%)	50	50	50	50	50	50

	Amplifier Output	C1	C2	C3	C4	C5	C6
Signal Scaling Factors (N/V, N•m/V)	± 5 V	500	500	1000	800	400	400
	± 10 V	250	250	500	400	200	200

The units of the analog Signal Scaling Factors are N/V for the force channels (C1, C2, C3), and N•m/V for the moment channels (C4, C5, C6). The force and moment values are calculated by multiplying the analog signal values with the corresponding Signal Scaling Factor. The Signal Scaling Factors are given for a gain of unity.

The Signal Scaling Factors and Analog Signal Output range given above do not apply to the USB output of the AM6500, the USB output of the AM6800, or force plates with a USB output.

Note: If your system / software is configured to accept a calibration matrix, enter a 6x6 diagonal matrix with the diagonal elements being C1, C2, C3, C4, C5 and C6. Set all off-diagonal elements to zero:

C1	0	0	0	0	0
0	C2	0	0	0	0
0	0	C3	0	0	0
0	0	0	C4	0	0
0	0	0	0	C5	0
0	0	0	0	0	C6