COLECOVISION PROGRAMMERS' MANUAL Rev. 5
©Coleco Industries, Inc. 1982
CONFIDENTIAL DOCUMENT - DO NOT COPY

APPENDIX H
OS SUBROUTINE LIBRARY

	•				L	-		<u>></u>	J E	31	١U	U	1	INE LIBRARY		
	BANK .			1	IF	10	P	VI	7	15	ER I	3	II		MENCAL PTION MCTION	
	ACTIVATE .			8	8		1		I	I	1		•		Hoves pattern and color generator be 3.3.2.4)
-	ABD416			E	1				I	8	I	T			Adds 8-bit signed (A) to 16-bit m- signed (HL)->(HL)	
	CONT_SCAR							I	T	T	T	T			Hoves controller port data to CRAN 6.4	
	SECLS:			2	2					I	I	T			Decrements least significant mibble 9.2	-
I	SBORSE			2	8				Ι	Τ	T	T			Desrements met significant mibble 6.3	
and the same	BECODER				1				Γ	T	T	T			Calls COST_SCAN 6.3	_
	SILLANOS		I	3	8	2	2	2	2	2	T	T	1		Doubles the gise of the original 3.2.2.4	
	PILL_VRAN		1	2	2	3	1	Γ	T	2	T	T	7		Writes a specific value to VRAN 3.1.5	-
	PRIB_SIGNAL			1					Γ	2	T	T	1		Releases a timer to the Free list 5.8	7
L	OUT_THAN		1		2	8	1			8		T	1	8	Revos TRAN table entry to CRAN 3.2.1.2	٦
	THIT SPR_ORDER			1						8	Ī	T	1		Initialises SPRITE_ORDER data area to 3.2.3.1	٦
	INTERNAL		1	·	8					2		T	1		Initializes the VDF base address for 3.2.2.1	ᅥ
	HIT TIME		1	1	2	B	8				Г	T	1		Initialises timer data areas 5.8	٦
L	INIT_SKITER		n	1	2					2		T	1		Initialises quoue size, head and tail 8.1	۲
L	EGAD_ASCII												T		Biddresses and gueus heed and tail Writes ASCII generator set to pattern generator table	٦
L	MCDE_1						1						T		Sets VDP to graphics mode 1 and 3.1.6	٦
L	RSITOL SI		2	1	•	T	1	1		1			T	7	(EL)—>byte.HSM So (EL)—>byte.LSM 9.8	۲
L	PLAT_IT				I	T	T	2	-	1		Г	T	7	Called to start a sound " 7.3	1
	PLAT_9080 S		Ī	T	T	T	T	1	1	1			T	7	Hoves frequency and attenuation 7.5	1
L	POLLER	I		I	T	T	T	7	1	1			T	1	Reads, decodes and debounces all 6.2	1
L	PETOS				T	T	1	2	1	1		8	1	1	Scrive portions of both controllers Changes an object's Trame or location 3.3.8	1
L	POT_VRAR	I	8	8	1		-	1	1	2	1				Nove data from CRAR to TRAR table 3.2.1.3	1
L	MID_000	I			T	T	1	1	1	1	1		l		16-bit random humber generator 9.5	1
Ŀ	BAD_REGISTER				I	T	T	1	1	1	1				Reads and returns the contents of 3.1.3 the VDF register	1
Ŀ	EAD_VEAR		2	3	1	1		1		T	1		T	1	Reads from WRAN writes to buffer in 3.1.1	1
Ŀ	EFLECT_BORI SONTAL			2	2	1.	1	1	1	T	T			1	Reflection of generators short the	1
R	EFLECT_VERTICAL		2	8	8	12	18	1	1	1	1		_	11	horizonta) axis Reflection of generator about the 3.2.2.3	- Transport
	EQUEST_SIGNAL		2	8		T	1	T	1	1	1	1		#	Sets up a timer for the maller 5.6	
R	אין פרו די פ	-	8	8	2	,	8	8	18	1	1	1		1	90-degree alectrise rotation of	
80	ORD_1879	T	1			1	8	T	T	1	T	1		₩	Initialises various sound data areas 7.2	The state of the s
90	OLO_BALII	I	1			T	T	1	T	1	T	1		1	Called every VDF interrupt; manages 7.6	
71	PT_P10κΔL	I	1				1	1	8	T	1	1		11	Tosts for a time-out of a timer ' 5.7	
97	MB_MOR		1				Γ	1.	T	1	1	1		1	Maintaine all 05 seftwarm timers 5.5	
87	DATE_SPIENDS								T	1	T	1		1	Services controller apinner switch 6.5	
un.	1700		J						T	T	1	T		11	Performs deferred PUTOBJ sperations 4.8	
100	ITS_REGISTER		J				2	8				1			frites a value to a selected VDP 3.1.0	
100	TTS_TRAIS	8		1		8	B	8				T		11	loves Data from CRAN to VAAR 3.2.3.2	
un,	187 m 79L		I						2		Γ	1		100	over local oprite data to VRAN 3.2.3.2	
												_	_			