

LifeLoop trainings

Clearing cache on Fire TV Stick

Displays

How to clear the cache on the Fire TV Stick.

lifeloop.com





Table of contents

Section 1:	Clearing cache on Fire TV Stick	1-3
Section 2:	FAQs	4
Section 3:	Continued learning	5






Clearing cache on Fire TV Stick

Step 1

Using the remote, navigate to settings on your tv.



If you have an older model, you will find settings at the top of your screen.






Clearing cache on Fire TV Stick


Step 2

Select applications.



Step 3

Next, select manage installed applications.





Clearing cache on Fire TV Stick


Step 4

Select the LifeLoop display app.



Step 5

Scroll down and select clear cache.





FAQs

Why does my display keep going black?

Fire TV Sticks released an update that is setting a "do not disturb" notification and "still watching" mode starting at four hours that turns the screen black after four hours of no use.

Why do I need to clear the cache?

Clearing cache helps the device run optimally, and in doing so, fixes certain issues like slow loading times, etc.



Continued learning

Visit the Learning Community

Access LifeLoop marketing collateral and training resources at your convenience. Find the Learning Community by clicking the "?" on the top right-hand side of your screen or going to https://training.lifeloop.com/training/staff.

Attend a University course

Don't forget about our complimentary LifeLoop University available to you and your team. Courses are provided weekly and cover all LifeLoop features. Emails with the topics and schedules are sent out monthly for you to register to attend.

Further questions?

Reach out to support@lifeloop.com or your Customer Success Manager.