

# NORA-W366 AT Command Cheat Sheet

---

**Firmware:** u-connectXpress v1.0.0-011

---

## 1. Test Communication

---

Check if the module is responding.

AT

Response:

OK

---

## 2. Module Information

---

Manufacturer

AT+GMI

Model

```
AT+GMM
```

Firmware Version

```
AT+CGMR
```

Serial Number

```
AT+CGSN
```

---

## 3. Echo

---

Disable echo

```
ATE0
```

Enable echo

```
ATE1
```

---

## 4. Error Handling

---

Enable detailed errors

```
AT+USYEE=1
```

Read last error

```
AT+USYEC?
```

## Common Errors

| Code | Meaning                 |
|------|-------------------------|
| 0    | No Error                |
| 5    | Invalid Parameter       |
| 32   | Unknown Command         |
| 34   | Invalid Syntax          |
| 35   | Operation Not Supported |

---

## 5. Restart Module

```
AT+CPWROFF
```

The module will reboot and print:

```
+STARTUP
```

---

## 6. Wi-Fi Scan

### Active Scan

```
AT+UWSSC=0
```

### Passive Scan

```
AT+UWSSC=1
```

## Example

```
+UWSSC:2887BA7C3C7F,"OfficeWiFi",7,-42,18,8,8
+UWSSC:6014665B68FB,"Guest",1,-60,18,8,8
OK
```

## Fields

```
BSSID
SSID
Channel
RSSI
...
```

---

# 7. Wi-Fi Events

---

## Connected

```
+UEWLU
```

## Disconnected

```
+UEWLD
```

## Network Down

```
+UEWSND
```

---

## 8. Save Settings

---

```
AT&W
```

---

## 9. Factory Reset

---

```
AT+USYFR
```

---

## 10. TCP Socket

---

Create TCP Socket

```
AT+USOCR=6
```

Connect

```
AT+USOCO=<socket>,"192.168.1.100",80
```

Send Data

```
AT+USOWS=<socket>,"Hello"
```

Receive Data

```
AT+USORF=<socket>,100
```

## Close Socket

```
AT+USOCL=<socket>
```

---

# 11. UDP

---

## Create Socket

```
AT+USOCR=17
```

## Send Packet

```
AT+USOST=<socket>,"192.168.1.50",5000,"Hello"
```

## Receive

```
AT+USORF=<socket>,100
```

---

# 12. MQTT (Basic)

---

## Connect

```
AT+UMQTTC
```

## Publish

```
AT+UMQPS
```

Subscribe

```
AT+UMQTS
```

Disconnect

```
AT+UMQTD
```

---

## 13. Bluetooth LE

---

Start Advertising

```
AT+UBTA
```

Stop Advertising

```
AT+UBTAD
```

Bluetooth Mode

```
AT+UBTM?
```

---

## 14. Useful Events

---

Wi-Fi Connected

```
+UEWLU
```

Wi-Fi Lost

+UEWLD

TCP Data Received

+UESODA

MQTT Data Received

+UEMQDA

Bluetooth Connected

+UUBTACLC

---

# Typical Workflow

---

```
AT
↓
AT+GMM
↓
AT+CGMR
↓
AT+USYEE=1
↓
AT+UWSSC=0
↓
Choose Wi-Fi
↓
Connect
↓
```



```
Open TCP Socket
↓
Send Data
↓
Receive Data
↓
Close Socket
```

---

## Commands Verified on Your Module

---

- ✓ AT
  - ✓ ATE0
  - ✓ ATE1
  - ✓ AT+GMI
  - ✓ AT+GMM
  - ✓ AT+CGMR
  - ✓ AT+CGSN
  - ✓ AT+USYEE=1
  - ✓ AT+USYEC?
  - ✓ AT+UWSSC=0
  - ✓ AT+CPWROFF
-

# Tips

---

- Use **115200 baud**, 8 data bits, no parity, 1 stop bit.
- Always terminate commands with **CR** (`\r`) or **CR+LF** (`\r\n`).
- Enable extended errors (`AT+USYEE=1`) during development.
- Save configuration with `AT&W` after changing persistent settings.
- Watch for unsolicited events (`+UEWLU`, `+UEWLD`, `+UEWSND`) while connected.