

XR-200 Installation Manual

1. Introduction

This manual describes the installation of the XR-200 control unit.

Read all safety instructions before installing the device.

2. Technical Specifications

Operating temperature: 10°C to 40°C

Supply voltage: 230 V AC, 50 Hz

Maximum load: 16 A

4. Maintenance

Inspect the cooling fan every 6 months.

Replace the air filter every 12 months or after 2000 operating hours.