

XR-200 Service Manual

1. Scope

This manual is intended for service technicians maintaining the XR-200.

3. Environmental Requirements

Operating temperature: 15°C to 35°C

Supply voltage: 230 V AC, 50 Hz