Flashing Instructions – STM32G031 (Smart Bulb)

Method: ST-Link

Tools Required:

* ST-Link programmer
* STM32CubeProgrammer software (install on PC)

Steps:

1. Connect ST-Link to the board:
   * SWDIO → SWDIO
   * SWCLK → SWCLK
   * GND → GND
   * 3.3V → VCC (if required)

2. Power the board.

3. Open STM32CubeProgrammer.

4. Select "ST-Link" as the connection type.

5. Click "Connect".

6. Load the firmware:
   * Click "Open File"
   * Select firmware.bin

7. Set the start address:

   0x08000000

8. Click "Download" or "Start Programming".

9. Wait until flashing completes.

10. Reset the board.

Result:

The firmware should now be running on the device.