Flashing Instructions ATtiny1616 (Remote)

Method: UPDI using Arduino IDE

Tools Required:

* Arduino IDE installed
* UPDI programmer OR Arduino configured as UPDI programmer

Steps:

1. Connect UPDI:

   * UPDI pin → programmer UPDI
   * GND → GND
   * VCC → 3.3V or 5V (as required)

2. Open Arduino IDE.

3. Install megaTinyCore (if not already installed).

4. Select Board:

   ATtiny1616

5. Select Programmer:

   "SerialUPDI" or equivalent

6. Load firmware:

* Use "Sketch → Upload Using Programmer"

* Select the firmware.hex file

7. Wait for upload to complete.

Result:

Firmware is now programmed into the ATtiny1616.