





ROOF TENT INSTRUCTIONS



Lamp

Product characteristics

Light mode	Hell	dimmed	Red light	Flashing red light
Lumen	185	60		
Light range	20 Meter			
Power supply	2 Lithium ion battery Type 18650 and 3 batteries type AA			
Weight	approx. 450 Gramm incl. Batterien			
Degree of protection	IPX5			
Material	plastic			






Function and structure

- The lamp has 15 LEDs of type 5730SMD with high brightness and 6 red LEDs.
- This product has a dual Power module for power supply with 2 rechargeable type 18650 lithium-ion batteries and 3 batteries type AA
- This camping light has a low energy consumption and very good lighting properties.
- The body is made of an aluminum alloy, as with aircraft is used, as well as high-strength ABS plastic.
- The luminaire has a standard USB port which can also be used. Mobile phones can be charged.





Manual

- Pull out the telescopic body to turn on the light.
- Push the lamp body back into the housing to switch off the light.
- With the lamp extended, press the button to set the light mode.
- The lamp switches in the order: bright - dimmed - red light - flashing red light.





ladder x 1





Complete ladder extension :

The ladder should be on a firm and level ground, move one foot on the lowest rung.

Pull the top-rung off and check if the buttons are locked (Scheme 5). Repeat the process with each of the next lower rung, until the ladder is completely extended.

Partial extension of the ladder :

- Place ladder on a firm and flat ground, move one foot on the lowest rung.
- Pull the lowest rung off and check if the buttons are locked (Scheme 5). Repeat the process with each of the next higher rungs, until the ladder is extended to desired length.



Caution:

Always check that all buttons are on the position "Locked" before climbing on the ladder.

Using the ladder:




1. Do not exceed the maximum total load.
2. Do not overreach, users should keep their buckle(navel) inside the stiles and both feet on the same step/rung throughout the task.
3. Do not step off a leaning ladder at a higher level without additional security, such as tying on or use of a suitable stability device.
4. Do not use standing ladders to access another level.
5. Do not stand on the top three steps / rungs of a leaning ladder.
6. Ladders should only be used for light work of short duration.
7. Do not use the ladder outside in adverse weather conditions, such as strong wind.
8. Take precautions against children playing on the ladder.
9. Face the ladder when ascending and descending.
10. Keep a secure grip on the ladder when ascending and descending.
11. Do not use the ladder as a bridge.
12. Wear suitable footwear when climbing a ladder.
13. Avoid excessive side loadings e.g drilling brick and concrete.
14. Do not spend long time on a ladder without regular breaks (tiredness is a risk).







Open the ladder:

Automatic locking: each rung of your ladder has 2 locking pins are blocked, automatically inserted into the slots of the uprights in place when the ladder is extended.

The two black buttons on both sides:

- Unlocked position(Scheme 4): There is a gap between the buttons and the spar
- Locked position(Scheme 5): The buttons are located directly on the spar.





Telescopic Ladder

Caution : Please read all of this leaflet carefully before using your telescopic ladder.

Before using:

1. Please ensure that you are fit enough to use the ladder, don't use the ladder under medication, alcohol or drug influence.
2. When transporting ladders on roof bars or in a truck, please ensure they are suitably placed to prevent damage.
3. Inspect the ladder after delivery and before first using to confirm condition and operation of all parts.
4. Visually check the ladder if it seems damaged. Check it before each working.
5. For professional users, regular periodic inspection is required.
6. Ensure the ladder is suitable for the task.
7. Do not use a damaged ladder.
8. Remove any contamination from the ladder such as wet paint, mud, oil or snow.
9. Before using a ladder at work, a risk assessment should be carried out respecting the legislation in the country of use.

Positioning and erecting the ladder

1. Inclination angle should not exceed 75 degree.
2. Ladder shall be on an even level and unmovable base.
3. Ladder should lean against a flat non-fragile surface and should be secured before using, e.g tied or use of suitable stability device.
4. When positioning the ladder, please take into account the risk of collision with the ladder e.g. from pedestrians, vehicles or doors and windows where possible in the work area.
5. Identify any electrical risks in the work area, such as overhead lines or other exposed electrical equipment.
6. Ladder shall be stood on its feet, not the rungs or steps.
7. Ladders shall not be positioned on slippery surface (such as ice, shiny surface or significantly contaminated solid surface) unless additional effective measures are taken to prevent the ladder from slipping.