CONFIG NANO STATION M2 P2P & PICO STATION M2HP AS AP

Note:

Topology (AP WDS ---- DISTANCE ---- STATION WDS & AP)

Internet Gateway ip 192.168.11.1/248

NanoStation M2(1) as AcessPoint WDS ip 192.168.11.2/248

NanoStation M2(2) as Station WDS ip 192.168.11.3/248

PicoStation M2HP as AcessPoint LAN ip 192.168.11.4/248


WLAN ip 192.168.100.1/24

Client DHCP ip 192.168.100.0/24




NanoStation M2 (1) as AP WDS


1. Default ip NS M2 192.168.1.20 with user & passwd ubnt.




2. set wireless & change.




3. set network & change.



4. set advanced, config distance depend on your location, then change.




5. set services, enable NTP client & change.



6. set system, change default user & passwd, then change.




7. enable airMax & change, then apply all config.




NanoStation M2 (2) as Station WDS


1. Default ip NS M2 192.168.1.20 with user & passwd ubnt.



2. set wireless & change.




3. set network & change.




4. set advanced, enable POE passthrough. (give power to secondary port, used by $picoStation\ M2HP$)




5. set services, enable NTP client & change.



6. set system, change default user & passwd then change & apply all config.




7. well done




PicoStation M2HP as AP


1. default ip PicoStation M2 is 192.168.1.20 with user & passwd ubnt.




2. set wireless & change.




3. set network & change.




4. set advanced & change.



5. set services, enable NTP client.




6. set system, change default user & passwd.



7. disable airMax & change, then apply all config.



8. try connect to wifi.



Dok 20/11/2015 padliyulian@ymail.com