SETUP NANO STATION 2 AS ACCESS POINT MODE


Note: Topology (Inet -- NS2 -- Clients).

NS2 LAN IP 192.168.1.251 / GW 192.168.1.88


NS2 WLAN IP 192.168.4.1 / DHCP mode On

Client 192.168.4.0/24 / GW 192.168.4.1


1. set wireless to AP mode, create SSID, create WPA key, and etc.




2. set network mode as router & config LAN, WLAN.




3. set network mode as router & config LAN, WLAN.




4. set advance, antenna settings (vertical / horizontal), distance etc depend on your needs.



5. for service set enable/disable depend on your needs. set system, should change your user & pwd.



6. cek status.



7. tes client.

