

MECHAI AUTOMOTIVE SERVICE MANUAL

Section 11: Engine Cooling System

General Description and Operating Principles:

The cooling system maintains engine operating temperature within the optimal range of 88C to 95C. A wax-pellet thermostat regulates coolant flow through the radiator.

WARNING: Never open radiator cap when engine is hot.

Thermostat Housing Bolt Torque: 12 Nm (106 in-lb).

Thermostat Replacement Procedure

- 1. Disconnect negative battery cable.
- 2. Drain engine coolant into a clean container.
- 3. Disconnect radiator upper hose from water outlet.
- 4. Remove water outlet fitting bolts and remove thermostat.
- 5. Install new thermostat with jiggle valve facing upward.
- 6. Tighten mounting bolts to specified torque (12 Nm).



Figure 11-1: Thermostat Assembly and Jiggle Valve Orientation

Cooling System Service Specifications Table:

Item	Specification	Limit
Thermostat Opening Valve	82 C (180 F)	80 - 84 C
Thermostat Full Open Lift	8.5 mm or more	Min 8.0 mm
Radiator Cap Relief Pressure	108 kPa	93 - 123 kPa