

TCL of nECO

Window

schCreateWindow

Description

Create a ECO window from selected set.

Syntax

```
schCreateWindow [-win window] -eco
```

Value Returned

nSchema window ID if successful; 0 otherwise.

Example

```
schCreateWindow -win $current_window -eco
```

ECO Utility

schChangeInstScope

Description

Move an instance to a specified scope with original connection kept. Immediately reflects the changes in all windows.

Syntax

```
schChangeInstScope [-win window] [-delim] -scope scopename [-inst  
instname] [-keynote comment]
```

Argument

-win *window*

The window ID of the invoking ECO window.

`-delim`

Specify delimiter.

`-scope`

Specify destination scope.

`-inst`

Specify instance.

`-keynote`

Specify comment string for source code changes.

Value Returned

1 if successful; 0 otherwise.

Example

```
schChangeInstScope -win $current_window -scope "system.CHILD1" -inst "MASTER"  
-keynote "Novas ECO updated by shelley Jul 6, 2001 18:16 "
```

schCloneLogic

Description

Duplicate selected logics in non-freeze silicon mode.

Syntax

```
schCloneLogic -scope scope -inst instlist [-prefix] [-retainInput] [-  
retainOutput] [-newscope newscope]
```

Argument

`-scope scope`

The original scope for the clone logic to be cloned from.

`-inst instlist`

The selected instances.

`-prefix`

Set the prefix for the new instances

`-retainInput`

Retain the input signal.

`-retainOutput`

Retain the output signal.

`-newscope newscope`

The destination of the scope for the clone logic.

Value Returned

1 if successful; 0 otherwise.

Example

```
schCloneLogic -scope "system.i_cpu.i_ALUB" -newscope "system" -inst "U280"
"U279" "U282" -prefix
```

schCloneModule

Description

Clone modules. Immediately reflects the changes in all windows.

Syntax

```
schCloneModule [-win window] inst-cell pair list
```

Argument

`Inst-cell pair list`

Specify instances and mapping new module names.

Value Returned

1 if successful; 0 otherwise.

Example

```
schCloneModule {sys.LS100_TOP.LINK_LIST_MGT.LLM_A_GAP,eco_GAP}
{sys.LS100_TOP.LINK_LIST_MGT.LLM_B_GAP,eco_GAP1}
```

schReplaceCellType

Description

Replace all cells at one time.

Syntax

```
schReplaceCellType -old oldCell -new newCell [-portMapping newport  
oldport|tie_up|tie_down...] [-addCmt -keynote comment]
```

Argument

-old *oldCell*

Specify the old cell name.

-new *newCell*

Browse the cell you want to replace with from the **Cell List**.

-portMapping

Specify a port mapping for an undetermined cell.

-addCmt

Add comment next to netlist change.

Value Returned

1 if successful; 0 otherwise.

Example

```
schReplaceCellType -win $_nSchema2 -old "IV" -new "IVP" -addCmt -keynote ""
```

File

ecoSaveHDL

Description

Save source code to destination directory.

Syntax

```
ecoSaveHDL [-dir dirname] [-update] [-scope scopename] [-orig] [-prefix  
fileprefix]
```

Argument

-dir

Specify destination directory. Note that the specified directory *dirname* must be existed and writable before saving.

-update

Save modified netlist files only.

-scope

If specified, save the source codes of the hierarchy under this specified scope.

-orig

Force to use the original path of each file to write to. The parameter *-dir* cannot co-exist with *-orig*.

-prefix

Specify the filename prefix of modified netlist files. If any filename-with-prefix of new netlist files exists in path being written to, a serial number (starting from 0) will be appended to the prefix to insure every new filename in the path is unique with the same serial number. *-prefix* is optional and it works with option *-orig* only (i.e.the modified files will overwrite the source ones without this option.).

Value Returned

1 if successful; 0 otherwise

Example

```
ecoSaveHDL -dir "/dar/design/update" -update
```

ecoSaveLogFile

Description

Save ECO report.

Syntax

```
ecoSaveLogFile filename [-append]
```

```
ecoSaveLogFile -commitLog <file>
```

Argument

filename

Specify filename.

-append

If file exists, append the file.

-commitLog <file>

Append extra commit report to ECO Report. <file> is the full path name of ECO Report.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoSaveLogFile "/dar/design/update/history.txt"
```

Edit

ecoAddInst

Description

Add an instance to ECO window.

Syntax

```
ecoAddInst -win window -sparecell ["spareCellName"] -inst  
["instanceName"] -consume [{"consumed_spare_cell_name"  
"new_instance_name"}]
```

Argument

-win *window*

The window ID of the invoking ECO window.

-sparecell

Pop up the **Spare Cell** form.

-inst

Specify name of the added instance.

-consume

Pop up the **Consumed Spare Cells** form.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoAddInst -sparecell "system.i_cpu.i_spare.spare0" -inst  
"system.i_cpu.i_ALUB1.newInst1"-consume {"system.i_cpu.i_spare.spare1"  
"system.i_cpu.i_ALUB2.newInst1"} {"system.i_cpu.i_spare.spare11"  
"system.i_cpu.i_ALUB3.newInst1"}
```

ecoDeleteInst

Description

Delete an instance from ECO window.

Syntax

```
ecoDeleteInst [-win window] [-delim delim] [-inst instname]
```

Argument

-win window

The window ID of the invoking ECO window.

-delim

Delimiter of the *name_list*.

-inst

If specified, delete the specified instance from ECO window. Otherwise, delete the selected instance from ECO window.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoDeleteInst -inst {system.i_cpu.u23}
```

ecoReplaceInst

Description

Replace master of instance with same port configuration.

Syntax

```
ecoReplaceInst [-delim delim] [-win window] -master cellname [-inst
instname] [-sparecell sparecell] -portMapping newport
oldport|tie_up|tie_down...
```

Argument

`-win window`

The window ID of the invoking ECO window.

`-delim`

Delimiter of the name_list.

`-master`

Specify new master cell name.

`-inst`

If specified, replace the master of the specified instance with specified master name. Otherwise, replace the master of selected instance.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoReplaceInstance -master "AN2" -portMapping "A" "A1" "Z" "tie_up"
```

ecoChangeInstScope

Description

Move an instance to a specified scope. Break original connection.

Syntax

```
ecoChangeInstScope [-delim delim] [-win window] -scope scopename [-inst
inst_name] [-new newname]
```

Argument

`-win window`

The window ID of the invoking ECO window.

`-delim`

Delimiter of the name_list.

-scope

Specify the new destination scope where the instance would be re-located.

-inst

If specified, relocate the instance to specified scope. Otherwise, relocate the selected instance.

-new

Specify the new name of the scope where the instance would be re-located.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoChangeInstScope -scope system.i_cpu.i_PCU -inst system.i_cpu.u23
```

ecoMakeConnection

NOTE: Both *ecoMakeConnection* and *ecoReConnect* shall be enhanced to be able to describe path information of multiple bit connection. For example, Connect *system.i_cpu.i_CCU.SUB1.P[0:3]* to *system.i_cpu.i_PCU.SUB1.data[0:3]* where *system.i_cpu.i_PCU.SUB1.data[3]* already connects to *system.i_cpu.sl*.

Description

Make connection between two instance ports.

Syntax

```
ecoMakeConnection [-win window] [-delim delim] [-map connection  
information] [-instport instance port -instport instance port]
```

Argument

-win window

The window ID of the invoking ECO window.

-delim

Delimiter of the name_list.

-map

If specified, use this connection map information to create port/net. Otherwise, use default name to make connection.

The connection-info format is as follows:

```
" default_net_name [fully_sepecified_signal_list] "
```

where `default_net_name` refers to the default name for new signals, and `fully_sepecified_signal_list` refers to a list of `fully_sepecified_signal` separated by space. For example:

```
-map " eco_n_1 "
```

```
-map "n781 system.i_cpu.i_ALUB.n781 Output system.i_cpu.i_CCU.n781  
Input".
```

The `fully_sepecified_signal` format:

```
signal-full-name [port-direction-value]
```

where `port-direction-value` is one of (InOut, Input and Output). For example:

```
system.i_cpu.i_ALUB.eco_n_1 InOut
```

Alternatively, `\` " may be used to quote the `default_net_name` and `fully_specified_signal`. By default, nECO will add `\` " to quote both `default_net_name` and `fully_specified_signal`. For example,

```
-map " \"eco_n_2\" \"system.i_cpu.i_CCU.n1 Input\"  
\"system.i_cpu.n3\" \"system.i_cpu.i_ALUB.n2 Input\" "
```

-instport

If specified, make connection between specified two instance ports. Otherwise, make connection of the two selected instance ports.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoMakeConnection  
-defaultname "data"  
-newport "system.i_cpu.i_CCU.data[0:3] Output" "system.i_cpu.i_PCU.data[0:2]  
Input"  
-newnet "system.i_cpu.data[0:2]"  
-conn { "system.i_cpu.i_CCU.SUB1.P[0:3]" "system.i_cpu.i_CCU.data[0:3]" }  
      { "system.i_cpu.i_CCU.data[0:3]" { "system.i_cpu.data[0:2]",  
      "system.i_cpu.s1" } }  
      { "system.i_cpu.i_PCU.data[0:2]" "system.i_cpu.data[0:2]" }  
      { "system.i_cpu.i_PCU.SUB1.data[0:2]" "system.i_cpu.i_PCU.data[0:2]" }
```

ecoDeleteConnection

Description

Delete connection from instance.

Syntax

```
ecoDeleteConnection [-win window] [-delim delim] [-instport instance port]
```

Argument

`-win window`

The window ID of the invoking ECO window.

`-delim`

Delimiter of the instance name.

`-instport`

If specified, delete the connection of specified instance port. Otherwise, delete connection of selected instance port.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoDeleteConnection -instport -instport system.i_cpu.u23 Z
```

ecoReconnect

Description

Reconnect inst-pin or inst-port to another net.

Syntax

```
ecoReconnect [-win window] -instpin instpin | -instport instport-new  
netname
```

Argument

`-win window`

The window ID of the invoking ECO window.

-instpin

Specify the hierarchical instance and pin name.

-instport

Specify the hierarchical instance and port name.

-new

Specify the net name to connect to.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoReConnect
-defaultname "data"
-newport "system.i_cpu.i_CCU.data[0:3] Output" "system.i_cpu.i_PCU.data[0:2]
Input"
-newnet "system.i_cpu.data[0:2]"
-conn {"system.i_cpu.i_CCU.SUB1.P[0:3]" "system.i_cpu.i_CCU.data[0:3]"}
      {"system.i_cpu.i_CCU.data[0:3]" {"system.i_cpu.data[0:2]",
      "system.i_cpu.sl"}}}
      {"system.i_cpu.i_PCU.data[0:2]" "system.i_cpu.data[0:2]"}
      {"system.i_cpu.i_PCU.SUB1.data[0:2]" "system.i_cpu.i_PCU.data[0:2]"}
```

ecoTieUp

Description

Tie connection to power net.

Syntax

```
ecoTieUp [-win window] [-delim] [-instport instanceport_list]
```

Argument

-win window

The window ID of the invoking ECO window.

-delim

Delimiter of the instance name.

-instport

If specified, tie the connection of specified instance port(s) to power net.
Otherwise, tie the selected instance port(s) to power net.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoTieUp -instport -instport system.i_cpu.u23 Z
```

ecoTieDown

Description

Tie connection to ground.

Syntax

```
ecoTipDown [-win window] [-delim delim] [-instport instanceport_list]
```

Argument

-win window

The window ID of the invoking ECO window.

-delim

Delimiter of the instance name.

-instport

If specified, tie the connection of specified instance port(s) to ground net.
Otherwise, tie the selected instance port(s) to ground net.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoTieDown -instport -instport system.i_cpu.u23 Z
```

ecoRedo

Description

Reverse execution to next state.

Syntax

```
ecoRedo [-win window]
```

Argument

`-win window`

The window ID of the invoking ECO window.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoRedo
```

ecoUndo

Description

Reverse execution to previous state.

Syntax

```
ecoUndo [-win window]
```

Argument

`-win window`

The window ID of the invoking ECO window.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoUndo
```

ecoRenameNet

Description

Rename net name with new net name.

Syntax

```
ecoRenameNet [-win window] [-delim delim] [-old old_name] -new new_name
```

Argument

`-win window`

The window ID of the invoking ECO window.

`-old`

If specified, replace the specified net with new name. Otherwise, replace the selected net with new net name.

`-new`

Specify the new name to replace with.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoRenameNet -old system.clk -new system.clk2
```

ecoRenameInst

Description

Rename instance with new name.

Syntax

```
ecoRenameInst [-win window] [-delim delim] [-inst instname] -new new_name
```

Argument

`-win window`

The window ID of the invoking ECO window.

`-delim`

Delimiter of the instance name.

`-inst`

Specify instance name.

`-new`

Specify new name.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoRenameInst -win $_nSchema3 -inst "system.i_cpu.i_ALUB.eco_i1" -new  
"myInst1"
```

ecoConnectToNet

Description

Connect the selected instance pin to the specified net on the pop-up window. Continuous assignment can be handled by **Connect to Net** as well.

Syntax

```
ecoConnectToNet [-win window] -assign "LHS" "RHS" -edit "New LHS" "New  
RHS"
```

Argument

`-win window`

The window ID of the invoking ECO window.

`-assign "LHS" "RHS"`

The continuous assignment.

`-edit "New LHS" "New RHS"`

Edit the new assignment.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoConnectToNet -win $_nSchema3 -assign "top.Gx.wire_2\[0:1\]"  
"top.Gx.wire_1\[0:1\]" -edit "top.Gx.wire_2\[0:1\]" "top.Gx.new\[1:0\]"
```

ecoTraceDrive

Description

Find the driver(s) of the specified signal or instance. If there is no specified signal or instance, the action is applied to the selected signal or instance.

Syntax

```
ecoTraceDriver [-delim delim] [-win window] [-signal signal_name | -inst inst_name]
```

Argument

`-win window`

The window ID of the invoking ECO window.

`-delim`

Delimiter of the name_list.

`-signal`

Specify the signal name.

`-inst`

Specify the lowest hierarchy instance name.

Value Returned

A list of scope and instance name for the first traced result. 1 if successful; 0 otherwise. If the invoking window is a *full hierarchy* window, then 1 if successful; 0 otherwise. If the invoking window is a *flatten* window, then this command is only applied to these two types of window.

Example

```
ecoTraceDrive -win $_nSchema3
```

ecoTraceLoad

Description

Find the load(s) of the specified signal or instance. If there is no specified signal or instance, the action is applied to the selected signal or instance.

Syntax

```
ecoTraceLoad [-delim delim] [-win window] [-signal signal_name | -inst inst_name]
```

Argument

`-win window`

The window ID of the invoking ECO window.

-delim

Delimiter of the name_list.

-signal

Specify the signal name.

-inst

Specify the lowest hierarchy instance name.

Value Returned

A list of scope and instance name for the first traced result if successful; 0 otherwise. If the invoking window is *full hierarchy* window, then 1 if successful; 0 otherwise. If the invoking window is *flatten* window, then this command is only applied to these two types of window.

Example

```
ecoTraceLoad -win $_nSchema3
```

ecoTraceConnectivity

Description

Find the connectivity(s) of the specified signal or instance. If there is no specified signal or instance, the action is applied to the selected signal or instance.

Syntax

```
ecoTraceConnectivity [-delim delim] [-win window] [-signal signal_name |  
-inst inst_name]
```

Argument

-win *window*

The window ID of the invoking ECO window.

-delim

Delimiter of the name_list.

-signal

Specify the signal name.

-inst

Specify the lowest hierarchy instance name.

Value Returned

A list of scope and instance name for the first traced result if successful; 0 otherwise. If the invoking window is *full hierarchy* window, then 1 if successful; 0 otherwise. If the invoking window is *flatten* window, then this command is only applied to these two types of window

Example

```
ecoTraceConnectivity -win $_nSchema3
```

ecoDeselectAll

Description

Deselect all.

Syntax

```
ecoDeselectAll [-win window]
```

Argument

`-win window`

The window ID of the invoking ECO window.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoDeselectAll
```

ecoAddBuffer

Description

Add the buffer (such as BUF, NOT) to a net.

Syntax

```
ecoAddBuffer [-win window] -scope scopeName -old oldScopeName -new  
newScopeName
```

Argument

`-win window`

The window ID of the invoking ECO window.

`-old oldScopeName`

Specify the old instance scope name.

`-new newScopeName`

Specify the new instance scope name.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoAddBuffer -win $_nSchema3 -master "IDRV16" -scope "system.i_cpu.i_CCU" -  
inst "eco_i3" -old " CH0" " eco_i3.Z" -new " eco_n6" " eco_i3.A" "  
\CH_reg\[0\] .Q"
```

ecoDelBuf

Description

Delete the buffer (such as BUF, NOT) to a net. It can handle continuous assignment as well.

Syntax

```
ecoDelBuf -assign "LHS" "RHS" -signal "reserved net"
```

Argument

`-assign "LHS" "RHS"`

The continuous assignment.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoDelBuf -win $_nSchema2 -inst "top.FUK.J1" -signal "top.FUK.wire_1" -remove  
"top.FUK.U_1"
```

ecoDeleteInst

Description

Delete the selected instance and the connections of its ports. If Freezed Silicon Mode is turned on, the deleted instance will be added to the spare cell list. It can handle continuous assignment as well.

Syntax

```
ecoDeleteInst -assign "LHS" "RHS"
```

Argument

```
-assign "LHS" "RHS"
```

The continuous assignment.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoDeleteInst -win $_nSchema2 -assign "top.FUK.wire_2" "top.FUK.wire_1"
```

ecoCloneModule

Description

Clone modules.

Syntax

```
ecoCloneModule [-win window] inst-cell pair list
```

Argument

```
-win window
```

The window ID of the invoking ECO window.

```
inst-cell pair list
```

Specify instances and mapping new module names.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoCloneModule -win $_nSchema3{sys.LS100_TOP.LINK_LIST_MGT.LLM_A_GAP,eco_GAP}  
{sys.LS100_TOP.LINK_LIST_MGT.LLM_B_GAP,eco_GAP1}
```

ecoCommit

Description

Commit all the changes to design. Reflect changes to all windows.

Syntax

```
ecoCommit [-win window] [-comment comment]
```

Argument

`-win window`

The window ID of the invoking ECO window.

`-comment`

If specified, put this comment on corresponding updated source code.

Otherwise, put the default comment *Novas ECO - date* on source codes.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoCommit
```

ecoCreatePort

Description

This command creates a port after you enter the **Module Name**, the **Port Name**, and the **Port Direction**.

Syntax

```
ecoCreatePort [-win window] -module "moduleName" -port "portName"  
-direction input|output|inout [-instports "instPortName"]
```

Argument

`-win window`

The window ID of the invoking ECO window.

`-module "moduleName"`

Specify the module name.

`-port "portName"`

Specify the port name.

`-direction input|output|inout`

Specify the direction from either **input**, **output**, or **inout**.

`-instports "instPortName"`

Specify the instant port name.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoCreatePort -win $_nSchema3 -module "ALUB" -port "newp1" -direction input \  
-instports "system.i_cpu.i_ALUB"
```

ecoDeletePort (for internal use only)

Description

After *nECO* commit, *nECO* will report a dummy port list. The command is for deleting any of the reported ports.

Syntax

```
ecoDeletePort -port portlist
```

Argument

`-win window`

The window ID of the invoking ECO window.

`-port`

Specify ports to be deleted.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoDeletePort -port system.i_cpu.i_ALUB.p1 system.i_cpu.i_PCU.p2
```

ecoAddViewObj

Description

Add instance to view objects set.

Syntax

```
ecoAddViewObj [-win window] [-delim delim] -inst list_instname
```

Argument

-win window

The window ID of the invoking ECO window.

-delim

Delimiter of the instance name.

-inst

Specify instance list to be added to view object set.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoAddViewObj -inst {system.i_cpu.alu} {system.i_cpu.U23}
```

ecoRemoveViewObj

Description

Remove viewing object. If not specified, applied to the selected.

Syntax

```
ecoRemoveViewObj [-win window] [-delim delim] [-inst list_instname]
```

Argument

-win window

The window ID of the invoking ECO window.

`-delim`

Delimiter of the instance name.

`-inst`

If specified, remove the specified instance from viewing object set of ECO window. Otherwise, remove the selected instance from viewing object set.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoRemoveViewObj -win $current_window -inst {system.i_cpu.alu}  
{system.i_cpu.U23}
```

ecoEditConcateNet

Description

Edit concate net.

Syntax

```
ecoEditConcateNet [-win window] [-signal signal] index newname pair list
```

Argument

`-win window`

The window ID of the invoking ECO window.

`-signal`

Signal name.

Index newname pair list

Specify indices of concate net and mapping new net names.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoEditConcateNet {1, nn1}
```

ecoSplitBus

Description

Split bus option.

Syntax

```
ecoSplitBus [-win window] -splitBus on|off
```

Argument

-win window

The window ID of the invoking ECO window.

-splitBus

Set split bus flag.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoSplitBus -win $_nSchema3 -splitBus on
```

ecoMoveObj

Description

Move object.

Syntax

```
ecoMoveObj [-win window] -offset dx dy
```

Argument

-win window

The window ID of the invoking ECO window.

-offset

Specify move offset.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoMoveObj -win $_nSchema3 -offset 3000 -2000
```

ecoChangePortDir

Description

After *nECO* commit, *nECO* will report a change port direction list. The command is for changing port direction of the reported ports.

Syntax

```
ecoChangePortDir port-dir pair list [-comment comment]
```

Argument

port-dir pair list

Specify port and mapping new direction

comment

If specified, put this comment on corresponding updated source code; otherwise, put the default comment *Novas ECO - date* on source codes.

Value Returned

1 if successful, 0 otherwise.

Example

```
ecoChangePortDir {top.U1.s1, Input}
```

Select

ecoSelect

Description

Select the instances or signals in a window.

Syntax

```
ecoSelect [-win window] [-delim delim] [-toggle] -inst instname  
ecoSelect [-win window] [-delim delim] [-toggle] -signal signalname  
ecoSelect [-win window] [-delim delim] [-toggle] -instport instname  
portname  
ecoSelect [-win window] [-delim delim] [-toggle] -port portname
```

Argument

`-win window`

The window ID of the invoking ECO window.

`-delim`

Delimiter of the `name_list`.

`-toggle`

Toggle the selected, deselect if it is in the selected set. Otherwise, add into the select set.

`-inst`

Specify the hierarchical instance name.

`-signal`

Specify the hierarchical signal name.

`-instport`

Specify the hierarchical instance and port name.

`-port`

Specify the hierarchical port name.

Value Returned

Number of objects selected.

Example

```
ecoSelect -win $current_window -toggle -signal {system.i_cpu.S1}  
ecoSelect -inst {system.i_cpu.i_ALUB.u23}  
ecoSelect -instport {system.i_cpu.i_ALUB.u23} A
```

Configuration

ecoSetPreference

Description

Set all the viewing option preferences for ECO window.

Syntax

```
ecoSetPreference {-freezeSilicon ( on -manageMode ( instName | cellNumber )  
| off ) | -input status_type | -output status_type | -nameRule prefix | -  
pinManage option | -spareCellColor color | -rColor color | -preNet prefix  
| -prePort prefix | -preInst prefix | -format format}
```

Argument

option

on | off

If it is on, it is in freeze silicon mode. Otherwise, it is in non-freeze silicon mode.

-manageMode instName

Formal Freeze Silicon management.

-manageMode cellNumber

Avant! spare-cell auto selection mode.

status_type

tie-up | tie-down | floating

-freezeSilicon

Set freeze silicon mode.

-pinManage

Specify spare cell pin management flag.

-input

Set default status for spare cell input pins.

-output

Set default status for spare cell output pins.

-nameRule

Specify prefix name for spare cell name.

-spareCellColor

Specify color for spare cells.

-rColor

Specify color for revised components.

-preNet

Specify default prefix for new net.

-prePort

Specify default prefix for new port.

-preInst

Specify default prefix for new instance.

-format

Specify comment default format.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoSetPreference -freezeSilicon on -input tieup -output tiedown -nameRule  
dummy -format "ECO updated by \${UserName} \${Date} \${Time} "
```

ecoSetOptions

Description

Set ECO window display options.

Syntax

```
ecoSetOptions [-win window] [-fanInOut on|off] [-keepPlace on|off]
```

Argument

-win *window*

The window ID of the invoking ECO window.

-fanInOut

Whether to display the fan in/out number on instance port.

`-keepPlace`

Whether keep placement after ECO operation.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoSetOptions -faninOut on
```

ecoDumpAU

Description

Dump the ECO change information.

Syntax

```
ecoDumpAU [-win window] [-fanInOut] | [-report]
```

Argument

`-win window`

The window ID of the invoking ECO window.

`-fanInOut`

Whether to display the fan in/out number on instance port.

`-report`

Dump ECO report.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoDumpAU -fanInOut
```

Spare Cell

ecoAddSpareCell

Description

Add instance(s) to spare cell form.

Syntax

```
ecoAddSpareCell [-win window] [-inst list_inst]
```

Argument

-win window

The window ID of the invoking ECO window.

-inst

Specify instances.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoAddSpareCell -win $_nSchema3 -inst  
"mmacell_bist_tb.dummy_scope.DUMMY_INST.spare_inst0"
```

ecoDeleteSpareCell

Description

Remove instance(s) from spare cell form.

Syntax

```
ecoDeleteSpareCell [-win window] [-inst listInst] -cellName [cellName]
```

Argument

-win window

The window ID of the invoking ECO window.

-inst

Specify instances.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoDeleteSpareCell -win $_nSchema3 -inst  
"mmacell_bist_tb.dummy_scope.DUMMY_INST.spare_inst0"
```

ecoLoadSpareCellFile

Description

Load spare cell file to spare cell form.

Syntax

```
ecoLoadSpareCellFile [-win window] -file fileName
```

Argument

-win *window*

The window ID of the invoking ECO window.

-file

Filename.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoLoadSpareCellFile -win $_nSchema3 -file "SaveSpareCell.log"
```

ecoSaveSpareCellFile

Description

Save listed spare cells in spare cell form to file.

Syntax

```
ecoSaveSpareCell [-win window] -file fileName
```

Argument

-win *window*

The window ID of the invoking ECO window.

-file

File name.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoSaveSpareCellFile -win $_nSchema3 -file "SaveSpareCell.log"
```

ecoSearchSpareCell

Description

Search matched instances and add to spare cell form.

Syntax

```
ecoSearchSpareCell [-win window] -nameRule "string" -wildcard
```

Argument

`-win window`

The window ID of the invoking ECO window.

`-nameRule`

Specify pattern.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoSearchSpareCell -win $_nSchema3 -nameRule "spare_"
```

ecoLoadSpareCellNum

Description

Import the spare cell list with instance name from file.

Syntax

```
ecoLoadSpareCellNum -file fileName
```

Argument

`-file fileName`

The file which contains the spare cell list with instance name.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoLoadSpareCellNum -file "spl.cnt"
```

ecoSaveSpareCellNum

Description

Save the number list to a file for further usage of spare cell functions.

Syntax

```
ecoSaveSpareCellNum -file fileName
```

Argument

`-file fileName`

The file which contains the spare cell list with instance name.

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoSaveSpareCellNum -file "spl.cnt"
```

ecoConfirmSpareCell

Description

Commit the spare cell number list.

Syntax

```
ecoConfirmSpareCell
```

Value Returned

1 if successful; 0 otherwise.

Example

```
ecoConfirmSpareCell
```