

IP-XACT export and import dialog help

IP-XACT export dialog help

1. Select the type of export from the drop down control in the dialog. Set the file type by selecting one among the IP-XACT component hierarchical IP-XACT component, IP_XACT design, or hierarchical IP-XACT design options.
2. To include descriptive values check the “Exclude Descriptive Values” check box.
3. To include source files, check the “Copy Source Files” checkbox.
4. To replace common prefix when generating the IP-XACT, enter a prefix string in the “Common Prefix Replacement” value field. It makes file names or environment variables relative.
5. Use the “Common File Prefix” entry to enable to replace the common file prefix by CommonPrefixReplacment parameter.
6. Set the “Output file name” entry to either a name or directory. The default name of <design>.xml will be used.
7. Set the “Output directory name” for the top the file name defaults to <design>.xml, and lower levels will use <design/component instance name>.xml.

IP-XACT export and import dialog help

IP-XACT import dialog help

1. Set the file type by selecting design, designConfiguration, generatorChain, or component from the dropdown control.
2. Specify the input file to read by entering a value in the “Input file name” control.
3. If “Lock component interfaces” is checked then top level interfaces and ports cannot be modified.

Close