

coreAssembler Help

Help: Workspace Options

Workspace options can be set in several ways

- `set_workspace_options` command
- Edit > Workspace Options menu item and dialog -- change options for the current workspace
- Edit > Preferences > Workspace Options menu item and dialog -- set options globally for new workspaces

You can access the *coreAssembler User Guide* instructions for setting workspace options by clicking on the topic:

[Setting Workspace Options](#)